

*Final
H. Schubert
2017
200 140*

TR-1739-11

LOW $p\text{CO}_2$ AIR-POLARIZED CO_2 CONCENTRATOR DEVELOPMENT

FINAL REPORT

by

F.H. Schubert

May 30, 1997

Distribution of this report is provided in the interest of information exchange. Responsibility for the contents resides in the authors or organization that prepared it.

Prepared Under Contract No. NASW-5019

by

Life Systems, Inc.
Cleveland, OH 44122

for

National Aeronautics and Space Administration

NASA Headquarters

FOREWORD

The work reported herein was conducted by Life Systems, Inc. at Cleveland, Ohio under Contract No. NASW-5019 for a two Phase (Phase I and II) Ground-based Space Station Experiment Development Study Program entitled "Low pCO₂ Air-Polarized CO₂ Concentrator Development." The period of performance for the total contract (Phase I and Phase II) was eighteen (18) months, or from 11/03/95 through 06/01/97.

The overall objective of this program is to complete the effort required to characterize the performance and applicability of the electrochemical Air-Polarized Carbon Dioxide Concentrator process technology for space missions requiring low (i.e., less than 3 mm Hg) CO₂ partial pressure in the cabin atmosphere.

The National Aeronautics and Space Administration assigned Dr. Maurice Averner as the Contracting Officer's Technical Representative. The Principal Investigator of the program was Mr. Franz H. Schubert. Technical support was provided by the following individuals:

M. T. Andras, Ph.D.	Project Management
D. N. Case	Mechanical and Electrical Test Hardware and Testing
M. Gene Lee, Ph.D.	Trade Studies, Electrochemistry

TABLE OF CONTENTS

	<u>PAGE</u>
LIST OF FIGURES	iv
LIST OF TABLES	vi
LIST OF ACRONYMS	vii
SUMMARY	1
KEY ACCOMPLISHMENTS	3
INTRODUCTION	4
Background	4
Program Objectives	6
Program Organization	6
End Products	8
Report Organization	8
AIR-POLARIZED CARBON DIOXIDE CONCENTRATION TECHNOLOGY DESCRIPTION	9
Electrochemical CO ₂ Separation	9
Electrochemical O ₂ Separation	12
Expected Impact of APC Process Technology on CO ₂ Removal for Space Applications	13
TEST HARDWARE DEVELOPMENT	14
Test Hardware Development Approach	14
O ₂ Separation Hardware	14
Electrochemical Module Hardware	14
Test Stand and Data Acquisition Hardware for the EOSM	16
CO ₂ Separation Hardware	16
Electrochemical Module Hardware	16
Test Stand and Data Acquisition Hardware for the ECSM	21

continued-

Table of Contents - continued

	<u>PAGE</u>
Integrated APC Hardware	21
Electrochemical Modules	21
Test Stands and Data Acquisition Hardware for the APC	21
TEST PROGRAM	30
Test Objectives	30
Selection and Definition of Initial Test Conditions	30
Electrochemical O ₂ Separation Testing	37
EOSM Test Sequence	37
EOSM Test Results	37
Electrochemical CO ₂ Separation Testing	45
ECSM Test Condition Verification	45
ECSM Test Sequence	48
ECSM Test Results	48
Integrated APC Testing	59
Adjustment of Test Conditions	59
APC Test Sequence	59
APC Test Results	62
Summary of Electrochemical Characteristics for APC Sizing	71
APC SIZING AND COMPARISONS	73
Requirements Definition and Comparison Criteria	73
APC System and Definition Sizing	76
Alternate CO ₂ Removal Systems Definition and Sizing	76
Electrochemical Depolarized CO ₂ Concentrator Technology	76
Four-Bed Molecular Sieve Technology	82
Solid Amine CO ₂ Absorption Technology	82
Lithium Hydroxide CO ₂ Absorption Technology	85

continued-

Table of Contents - continued

	<u>PAGE</u>
CO ₂ Removal System Comparison Summary	90
Projected APC Space Station Flight Experiment (Phase II) Configuration	90
CONCLUSIONS AND RECOMMENDATIONS	94
APPENDIX A, TEST GRIDS	A-1
APPENDIX B, DATA SHEETS	A-2
REFERENCES	
NASA FORM 298	

LIST OF FIGURES

<u>FIGURE</u>		<u>PAGE</u>
1	SSP CO ₂ Concentrator Study Total Equivalent Weight vs. pCO ₂ Solar Collector Thermal Source	5
2	Block Diagram of APC CO ₂ Removal System	7
3	Electrochemical CO ₂ Separator Functional Schematic	10
4	Electrochemical O ₂ Separator Functional Schematic	11
5	EOSM Test Setup Mechanical Schematic with Sensors	17
6	EOSM Data Acquisition System	19
7	ECSM Test Setup Mechanical Schematic with Sensors	22
8	ECSM Data Acquisition System	24
9	ECSM Test Setup Mechanical Schematic with Sensors for Integrated APC Operation	26
10	EOSM Test Setup Mechanical Schematic with Sensors for Integrated APC Operation	27
11	APC Data Acquisition System	28
12	APC Integrated Test Setup	29
13	Water Vapor Pressure for Aqueous H ₃ PO ₄	33
14	Water Vapor Pressure of LSI-D Electrolyte	34
15	ECSM Anode Vent Gas Composition as a Function of CO ₂ Removal Efficiency	35
16	Nominal Inlet Air Humidity Conditions Used for APC Tests	38
17	Effect of Current on EOSM Cell Voltage with Pure O ₂ Feed	39
18	Effect of Current on EOSM Cell Voltage with 54±2% CO ₂ in Feed . . .	40
19	EOSM Cell Voltage and CO ₂ Composition in the EOSM Outlet Versus EOSM to ECSM Current Percentage	41
20	Effect of Variable CO ₂ in EOSM Feed Stream on EOSM Cell Voltage	42
21	Comparison of Effect of Cell Current on EOSM Cell Voltage with Pure O ₂ with Previous Data	43
22	Comparison of EOSM Cell Voltage and CO ₂ Composition in the EOSM Outlet Versus EOSM Current with Previous Data	44
23	Effect of Current on ECSM Cell Voltage (Air Inlet pCO ₂ - 0.3 mm Hg)	49
24	Effect of Current on ECSM Cell Voltage (Air Inlet pCO ₂ - 1.25 mm Hg)	50
25	Effect of Current on ECSM Cell Voltage (Air Inlet pCO ₂ - 2.2 mm Hg)	51
26	Effect of Current on ECSM Cell Voltage (Air Inlet pCO ₂ - 3.6 mm Hg)	52

continued-

List of Figures - continued

	<u>PAGE</u>
27 Effect of Current on ECSM CO ₂ Transfer Efficiency (Air Inlet pCO ₂ - 0.3 mm Hg)	53
28 Effect of Current on ECSM CO ₂ Transfer Efficiency (Air Inlet pCO ₂ - 1.25 mm Hg)	54
29 Effect of Current on ECSM CO ₂ Transfer Efficiency (Air Inlet pCO ₂ - 2.2 mm Hg)	55
30 Effect of Current on ECSM CO ₂ Transfer Efficiency (Air Inlet pCO ₂ - 3.6 mm Hg)	56
31 ECSM Cell Voltage and CO ₂ Transfer Efficiency Versus Inlet Air pCO ₂ at Nominal Cell current of 8.0 A	57
32 Comparison of ECSM Cell Voltage and CO ₂ Transfer Efficiency Versus Current Density with Past Data	58
33 APC ECSM Cell Voltage and CO ₂ Transfer Efficiency Versus Inlet Air pCO ₂ at Nominal Cell Current of 8.0 A	63
34 Inlet Air Humidity Conditions Used for APC Tests	64
35 Effect of Air Inlet Relative Humidity on APC CO ₂ Transfer Efficiency (Air Inlet pCO ₂ = 2.2 mm Hg)	65
36 Effect of Air Inlet Relative Humidity on APC ECSM Cell Voltage (Air Inlet pCO ₂ = 2.2 mm Hg)	66
37 APC ECSM CO ₂ Transfer Efficiency Versus Cell Current for Selected CO ₂ Inlet Compositions	67
38 Effect of Current on APC ECSM Cell Voltage	68
39 Effect of Current on APC EOSM Cell Voltage	69
40 EOSM Current Expressed as Percentage of ECSM Current	70
41 Block Diagram of EDC CO ₂ Removal System	80
42 Block Diagram of 4-Bed Molecular Sieve CO ₂ Removal System	83
43 Block Diagram of Solid Amine CO ₂ Removal System	86
44 Block Diagram of Lithium Hydroxide CO ₂ Removal System	88
45 APC Subsystem Mechanical Schematic with Sensors	92
46 Four-Person Capacity EDC Hardware Similarly to APC Flight Hardware Configuration	94

LIST OF TABLES

<u>TABLE</u>		<u>PAGE</u>
1	EOS Cell Component Characteristics	15
2	ECS Cell Component Characteristics	20
3	Initial Five-Cell Electrochemical Oxygen Separation Module (EOSM) Operating Parameters	31
4	Initial Five-Cell Electrochemical Carbon Dioxide Separation Module (ECSM) Operating Parameters	32
5	Five-Cell Carbon Dioxide (CO ₂) Concentration Process	36
6	Five-Cell Electrochemical Carbon Dioxide Separation Module (ECSM) Operating Parameters	46
7	Five-Cell Electrochemical Oxygen Separation Module (EOSM) Operating Parameters	47
8	Five-Cell Electrochemical Carbon Dioxide Separation Module (ECSM) Operating Parameters	60
9	Five-Cell Electrochemical Oxygen Separation Module (EOSM) Operating Parameters	61
10	Physical and Performance Characteristics for Electrochemical Module Sizing for APC Application	72
11	Space Station Atmosphere Requirements	74
12	CO ₂ Removal System Sizing and Comparison Criteria	75
13	Projected Physical and Operational Characteristics of the Air-Polarized CO ₂ Concentrator	77
14	Projected Physical and Operational Characteristics of the Electrochemical Depolarized CO ₂ Concentrator (EDC)	81
15	Projected Physical and Operational Characteristics of the Four-Bed Molecular Sieve CO ₂ Removal System	84
16	Projected Physical and Operational Characteristics of a Steam Desorbed Solid Amine CO ₂ Removal System	87
17	Projected Physical and Operational Characteristics of the Lithium Hydroxide CO ₂ Removal System	89
18	Equivalent Weight Comparison of Four-Person Capacity CO ₂ Removal Systems for Space Application at a pCO ₂ of 3 mm Hg	91
19	Current Status of APC Components Flight Readiness	93

LIST OF ACRONYMS

4BMS	Four-Bed Molecular Sieve
APC	Air-Polarized CO ₂ Concentrator
ARS	Air Revitalization System
ECLSS	Environmental Control and Life Support Systems
ECS	Electrochemical CO ₂ Separator
EDC	Electrochemical CO ₂ Concentrator
EOS	Electrochemical O ₂ Separator
ERCA	Electrochemically Regenerable CO ₂ and Moisture Absorption
ISS	International Space Station
LiOH	Lithium Hydroxide
MCUs	Multi-Cell Units
NASA	National Aeronautics and Space Administration
pCO ₂	CO ₂ partial pressure
SAWD	Solid Amine Water Desorbed
WVE	Water Vapor Electrolysis

SUMMARY

This report documents the results of Life Systems' work for the "Low pCO₂ Air-Polarized Carbon Dioxide Concentrator Development" Program. The objectives of the program were to complete the effort required to verify the performance and applicability of the hydrogen-less electrochemical Air-Polarized Carbon Dioxide Concentration process for space missions requiring low carbon dioxide partial pressure, i.e., less than 3 mm Hg, in the cabin atmosphere. The performance and applicability was to be verified by performing actual testing using multi-cell modules. The multi-cell modules to be used were to be of an approximate one-person capacity (2.20 lb carbon dioxide removal per a 24-hr period) to demonstrate the technology at a readily scalable size.

Achieving low pCO₂ atmospheres in a space station or equivalent environment is important because:

1. High carbon dioxide levels of greater than 0.3% (2.3 mm Hg) will have impact on interpretability of microgravity experiment data which will limit the usefulness of a space station for scientific experiments.
2. Although the existing spacecraft standards relating to crew health/safety are not clear as to time limits of exposure, exposure of crew to high carbon dioxide levels in long duration space missions is regarded as highly undesirable.

As part of this development program the two key components of an air-polarized system, i.e., the Electrochemical Carbon Dioxide Separator Module and the Electrochemical Oxygen Separator Module, were fabricated and assembled into test stands equipped with various test support functions. Testing was conducted to characterize the performances of the Electrochemical Carbon Dioxide Separator Module and the Electrochemical Oxygen Separator Module, first separately and then integrated as an Air-Polarized Carbon Dioxide Concentrator.

The testing of the Integrated Air-Polarized Carbon Dioxide Concentrator demonstrated that: (1) carbon dioxide removal efficiencies were as high as 75% at 2.2 mm Hg (0.29%) and were still at 26% even at low, earth equivalent, ambient pCO₂ levels of 0.29 mm Hg (0.038%), and (2) carbon dioxide concentrations of higher than 95% can be achieved at the Electrochemical Oxygen Separator Module outlet without causing high Electrochemical Oxygen Separator Module cell voltages and while maintaining a 100% nominal oxygen transfer efficiency.

Using the test data obtained with the approximately one-person capacity Integrated Air-Polarized Concentrator, the characteristics for a four-person capacity system were projected. The results showed, a system sized to operate at a 2.2 mm Hg (0.29%) carbon dioxide level has a weight of 252 lb, a volume of 7.0 ft³ and consumes 566 W of electrical power.

To compare the air-polarized concentrator technology with other candidate carbon dioxide removal systems, a study was completed comparing four-person capacity systems at 3 mm Hg and 2.2 mm Hg pCO₂. The candidate systems selected were an Electrochemical Depolarized Carbon Dioxide Concentrator, a Four-Bed Molecular Sieve, a Steam Adsorbed Solid Amine system and a Lithium Hydroxide based carbon dioxide removal system. As expected, the Electrochemical Depolarized Concentrator (using hydrogen) had the lowest equivalent weight considering launch weight and weight equivalents for power, heat load, propulsion, expendibles and oxygen consumption. The Air-Polarized Concentrator, however, compared well achieving the second lowest equivalent weight (after the electrochemical carbon dioxide concentration) compared to the other systems. The four person capacity APC characterized and defined herein is a candidate for a Space Station Flight Experiment that can generate desirable low pCO₂ levels of the station while proving the APC technology in a microgravity environment.

KEY ACCOMPLISHMENTS

The following key accomplishments resulted from completing the programs efforts.

- Verified the capability of the hydrogen-less electrochemical Air-Polarized Carbon Dioxide Concentrator to efficiently remove carbon dioxide from atmospheres having a partial carbon dioxide pressure as low as 0.29 mm Hg (0.038%), or equivalent to near earth ambient levels.
- Characterized the performance of five-cell electrochemical modules using flight-like 0.5 ft² cell hardware components for the electrochemical carbon dioxide separation and the electrochemical oxygen separation processes, providing results readily scalable to multi-person capacity systems.
- Defined a consistent set of nominal operating conditions for each individual electrochemical module to provide for their successful interaction when forming part of an integrated Air-Polarized Carbon Dioxide Concentration system.
- Successfully demonstrated integrated Air-Polarized Carbon Dioxide Concentrator system operation at a near one person capacity level over a wide range of key process parameters.
- Defined nominal operating conditions and physical characteristics for an Air-Polarized Carbon Dioxide Concentrator system to allow scaling to the four-person capacity level for eventual use as a Phase II Space Station Flight Experiment.
- Defined and established requirements and evaluation criteria to allow comparisons of candidate carbon dioxide removal technologies.
- Sized four other candidate carbon dioxide removal systems at the four-person capacity level and compared them with the Air-Polarized Carbon Dioxide Concentrator using total equivalent weight as a basis.

INTRODUCTION

During the past decade various technologies for removing carbon dioxide (CO₂) from air by a variety of methods have been developed for projected space applications. Under the sponsorship of the National Aeronautics and Space Administration (NASA), Life Systems has been involved in the development of various electrochemical CO₂ separation and processing concepts for use in space Environmental Control and Life Support Systems (ECLSS). These developments included the Electrochemical Carbon Dioxide Concentrator (EDC) using hydrogen (H₂), the Electrochemically Regenerable CO₂ and Moisture Absorption (ERCA) and the H₂-less Electrochemical CO₂ Separation (ECS) technology for use in Air-Polarized CO₂ Concentrators (APC).

While the EDC has always been known as the system characterized by low weight, power and volume, especially at pCO₂ levels equal to or less than 3 mm Hg^(1,2) (see Figure 1)⁽¹⁾, the use of H₂ may not be desirable for some applications. As a result, Life Systems, under the sponsorship of NASA, developed the APC, i.e., an electrochemical H₂-less CO₂ separation process for those applications where H₂ use may not be desirable.

Projections of APC-based system studies had shown promise for the APC to be competitive, i.e., have equal to or better weight, power and volume characteristics, than other competing non-electrochemical techniques. Single and two cell development programs supported this promise^(3,4,5) and resulted in the award of the current program to quantify, by testing, at a scaled up one person CO₂ removal level, APC operations to support these projections. Special emphasis was to be placed on operation at the lower pCO₂ levels projected and desirable for future space atmosphere requirements.

Background

Future long duration manned missions will require regenerative environmental control techniques to provide a habitable closed cabin atmosphere. An effective technique for removing CO₂ from the cabin atmosphere employs an electrochemical process for transferring CO₂ from a low pCO₂ environment in the cabin atmosphere to a higher pCO₂ stream isolated from the atmosphere. Achieving low pCO₂ atmospheres in space station environments is of paramount importance for the following reasons:

1. Carbon dioxide levels greater than 0.3% (2.3 mm Hg) will impact the interpretability of microgravity experiment data and limit the usefulness of platforms such as the Space Station for scientific experiments.
2. Although existing spacecraft standards related to crew health and safety are not well established with respect to CO₂ exposure limits, the exposure of crewmembers to high CO₂ levels in long duration space missions is regarded as highly undesirable.

(1) Numbers in parentheses refer to references listed in the Reference Section.




FIGURE 1 SSP CO₂ CONCENTRATOR STUDY TOTAL EQUIVALENT WEIGHT VS. pCO₂ SOLAR COLLECTOR THERMAL SOURCE

Life Systems, in collaboration with NASA, developed the APC process^(3,4,5,6) which is an advanced electrochemical concept for continuous removal of metabolic CO₂ from cabin atmospheres at pCO₂ level as low as < 1 mm Hg. This technology requires electrical power but no expendables, such as H₂.

The APC process occurs in two stages. In the first stage, CO₂ is separated from the cabin atmosphere via an Electrochemical CO₂ Separator (ECS). This process involves the transfer of oxygen (O₂) as well as the transfer of CO₂. In the second stage, O₂ is removed from the CO₂/O₂ mixture via an Electrochemical O₂ Separator (EOS). This separation results in CO₂ concentrations in excess of 90%. A block diagram of the APC process technology, which is a combination of the ECS and the EOS processes, is shown in Figure 2. A detailed process description of the APC technology is presented in a later section of this report.

Program Objective

The objective of this Space Station Experiment Development Study Program is to verify the performance and applicability of the electrochemical CO₂ APC process technology for space missions requiring low CO₂ partial pressures (pCO₂), i.e., less than 3 mm Hg, in the cabin atmosphere. This effort was to be implemented by performing actual testing using Multi-Cell Units (MCUs) with flight-sized cells for verification of the performance characteristics projected in prior advanced electrochemical CO₂ removal technology study programs. The MCUs to be used were to be of an approximate one-person capacity (2.20 lb CO₂ removal per a 24-hr period) to demonstrate the technology at a readily scalable size.

Program Organization


To fulfill the objectives of this Ground-based Space Station Experiment Development Study Program, the program's technical efforts were divided into six (6) major tasks:

Task

- 1.0 Review and compare APC process technology with other CO₂ removal technologies intended for space applications.
- 2.0 Determine the scale-up modifications required to operate the ECS and EOS modules at an approximate one-person capacity.
- 3.0 Fabricate and assemble the ECS and EOS modules and test stands.
- 4.0 Verify the projections of the APC process technology for comparison to other CO₂ removal technologies through testing and analysis.
- 5.0 Prepare required documentation and implement data management activities.
- 6.0 Perform required program management.

10-28-96

FIGURE 2 BLOCK DIAGRAM OF APC CO₂ REMOVAL SYSTEM



End Products

The end products of this Ground-based Space Station Experiment Development Study Program are:

1. An expanded APC technology experimental database based on multi-cell electrochemical module tests.
2. A four person capacity APC-based CO₂ removal system definition based on the test results obtained.
3. A comparison of system level characteristics (weight, power, volume, etc.) of the four person capacity APC-based CO₂ removal system with other CO₂ removal systems.
4. A Preliminary definition of a full sized APC Space Station Flight Experiment Unit.
5. Six Quarterly Reports documenting the progress of the contractual efforts.
6. A Final Report summarizing the ground-based development program results.

Report Organization

This report is organized into four major sections in addition to this Introduction. These sections are followed by the conclusions and recommendations reached based on the work reported herein. The four major sections are:

- Air-Polarized Carbon Dioxide Concentrator Technology Description
- Test Hardware Development
- Test Program
- Air-Polarized Carbon Dioxide Concentrator Sizing and Comparisons

Two appendices are included, Appendices A and B, containing test criteria and data sheets, respectively, for the program testing completed. The appendices are followed by references and Standard NASA Form 298.

AIR-POLARIZED CARBON DIOXIDE CONCENTRATION TECHNOLOGY DESCRIPTION

The APC process occurs in two stages. In the first stage, CO₂ is separated from the cabin atmosphere via an ECS. This process involves the transfer of O₂ as well as the transfer of CO₂. In the second stage, O₂ is removed from the CO₂/O₂ mixture via an EOS. This separation results in CO₂ concentrations in excess of 90%. The functional schematics of the ECS and EOS processes are shown in Figure 3 and 4, respectively. A block diagram of the APC process technology, which is a combination of the ECS and the EOS processes, was shown in Figure 2.



Details of the electrochemical CO₂ separation and electrochemical O₂ separation processes are described below.

Electrochemical CO₂ Separation


The electrochemical CO₂ separation process removes CO₂ from the cabin atmosphere by reacting the CO₂ with hydroxyl ions (OH⁻) electrochemically generated within a porous gas diffusion cathode according to the following half-cell reaction:




The CO₂ reacts with the OH⁻ and is then transferred within the aqueous alkaline carbonate electrolyte from the cathode (atmosphere side) to the anode (CO₂ concentrating side). The CO₂ transfer occurs via carbonate (CO₃⁻²) and bicarbonate (HCO₃⁻) ions generated from the reaction of CO₂ with OH⁻ according to Reactions 2a and 2b, respectively:



Reaction 2b occurs instantaneously, so Reaction 2a is the rate-determining step. Therefore, the conversion of CO₂ to CO₃⁻² can be described by a single step as shown in Reaction 3:




When the concentration of OH⁻ is depleted, additional CO₂ can be absorbed by:



Combining Equations 3 and 4 results in an overall absorption reaction of:





Electrode Reactions:







FIGURE 3 ELECTROCHEMICAL CO₂ SEPARATOR FUNCTIONAL SCHEMATIC



Electrode Reactions:







FIGURE 4 ELECTROCHEMICAL O₂ SEPARATOR FUNCTIONAL SCHEMATIC


The CO_3^{-2} and HCO_3^- ions formed at the cathode by Reactions 3 and 5, respectively, migrate toward the anode due to an electrical potential difference applied to the cell. The CO_2 is liberated within the electrolyte at the anode according to the following equations:




and



Combining Reactions 1, 3 and 6a results in a net overall reaction of:



and combining Reactions 1, 5 and 6b results in a net overall reaction of:





Reactions 7a and 7b represent the results of two different CO_2 transfer mechanisms which determine the electrochemical transfer efficiency of the CO_2 removal process. Reaction 7a shows that two moles of CO_2 are transferred per mole of O_2 compared to the four moles of CO_2 per mole of O_2 transferred per Reaction 7b. Whether the CO_2 transfer occurs mostly by Reaction 7a or Reaction 7b depends on several factors such as atmospheric CO_2 level, air flow rate, electrochemical cell current, operating temperature, etc. In this report Reaction 7a will be used for CO_2 removal efficiency calculations, i.e., transfer of one mole of CO_2 per 1/2 mole of O_2 co-transferred is equal to 100%.

Electrochemical O_2 Separation

As shown in Reactions 7a and 7b, the transfer of CO_2 from the cathode (atmosphere side) to the anode involves the transfer of O_2 . The concentration of O_2 in the anode gas stream is dependent on the CO_2 transfer efficiency. The O_2 must be removed from the anode gas stream to yield a high CO_2 concentration for efficient downstream O_2 recovery processing (e.g., CO_2 reduction followed by water electrolysis).

As part of the APC technology, an electrochemical O_2 separation process is used to generate concentrated CO_2 by removing O_2 from the CO_2/O_2 mixture stream. An aqueous acidic electrolyte is used in the EOS cell core to prevent the transfer of CO_2 while allowing the transfer of O_2 . This transfer of O_2 occurs via water molecules which diffuse from the cathode to the anode where they are dissociated into O_2 and hydrogen ions according to Reactions 8 and 9, respectively:



The overall reaction is:



which results in an increased CO_2 concentration in the cathode gas stream of the EOS. The concentrated CO_2 stream is sent to CO_2 reduction processes such as the Sabatier or the Bosch processor to eventually recover O_2 . The O_2 produced at the anode is sent to the space cabin.

Expected Impact of APC Process Technology on CO_2 Removal for Space Applications

The APC process offers advanced electrochemical technology for the continuous removal of metabolic CO_2 from cabin atmosphere at low $p\text{CO}_2$ and will provide substantial gains to an overall Air Revitalization System (ARS):

- Continuous removal of CO_2 from the cabin atmosphere resulting in more uniform CO_2 concentration levels in the cabin atmosphere.
- An efficient H_2 -less electrochemical CO_2 concentration technique.
- Variable CO_2 removal rates through control of cell current, air flow rate, etc.
- Minimal thermal heat loads and simple basic operating mode transitions due to operation at near ambient temperature and pressure.
- Variable capacity through addition or elimination of the number of electrochemical cells in the modules.
- Reduced power consumption, weight and volume requirements due to absence of expendables or regenerative processing.

TEST HARDWARE DEVELOPMENT

Two electrochemical modules, one for O₂ separation, one for CO₂ separation and associated mechanical and electrical test hardware were developed. The test hardware provided the flexibility to allow separate EOSM and ECSM testing, as well as provide for integrated APC testing. Special test equipment to allow for data acquisition and analysis was provided.

Test Hardware Development Approach

The hardware development approach chosen was consistent with the overall scope of the program, i.e., utilizing, to the maximum extent possible, existing Life Systems' electrochemical cell and test stand hardware. This approach included cost effective modifications of existing hardware where applicable.

A requirement adopted for the electrochemical cells at the beginning of the Program was that the active electrode area was to be similar to flight-like projections (i.e., 0.5 ft² per cell). Module size at a given set of operating conditions was to be equivalent to approximately a one-person CO₂ removal capacity (i.e., 2.2 CO₂ lb/day).

Ancillary mechanical and electrical components that would normally compliment the electrochemical modules to form a complete APC flight system were to be simulated using existing test stand or other hardware items. The hardware to be developed for the program testing had to allow for independent EOSM and ECSM testing as well as to be easily modifiable to complete an integrated APC test program.

O₂ Separation Hardware

The O₂ separation hardware consisted of a five-cell electrochemical module and its associated test stand and data acquisition hardware.

Electrochemical Module Hardware

Existing Water Vapor Electrolysis (WVE) cell and module hardware was used as a basis to develop a five-cell EOSM. Injection molded polysulfone cell frames with integral liquid coolant compartments and current distribution and collection components formed the primary building block of a five-cell EOSM. The heart of each cell, the unitized cell core, consisted of an anode, a cathode and an acid compatible separator, molded together with gas passage spacer screens into the unitized cell core assembly. End plates were constructed of glass filled polysulfone and all sealing was accomplished via commercial or specially molded Viton O-rings. Each unitized cell core was charged with phosphoric acid (H₃PO₄) electrolyte using Life Systems' electrochemical cell charging fixtures. Table 1 lists characteristics of key electrochemical cell components for the EOSM.

TABLE 1 EOS CELL COMPONENT CHARACTERISTICS

<u>Component</u>	<u>Material</u>	<u>Thickness, in</u>
Cathode Gas Cavity Spacer	Ti Exmet	0.050
Cathode Electrode	Noble Metal Catalyst on Pt Screen	0.011
Matrix	Mineral-based	0.015
Anode Electrode	Metal Oxides on Porous Ti Plaque	0.032
Anode Gas Cavity Spacer	Ti Exmet	0.100

The five electrochemical cells were arranged to provide for O₂/CO₂ mixture flow in series through the five cells and for parallel collection of the cathode product gas (O₂). Electrical current was routed to flow in series through the five cells. Liquid coolant passages were arranged to allow for parallel liquid coolant flow.

Test Stand and Data Acquisition Hardware for the EOSM

An existing test stand was modified to allow for EOSM testing, resulting in the schematic shown in Figure 5. The associated data acquisition system concept is shown in Figure 6. The EOSM test stand provided for measured and controlled flows of O₂ and CO₂ from bottled storage and for adjustable backpressure regulation of the cathode exit gas. A controllable and measurable liquid coolant flow supply was included, equipped with inlet and outlet temperature sensors. Multiple two-way and three-way valves completed the test hardware allowing for proper characterization of influent and effluent gas flows.

Electrically the test stand provided for adjustable module current and for associated module and cell voltage readouts and monitoring. Shutdown protection for high cell voltages was incorporated to safely and automatically shutdown the test should limits be exceeded.

Key data acquisition items included a Lira 3000 CO₂ Analyzer and a multi-channel Molytek data logger. Flow measurements were made using calibrated flow meters for the O₂ and CO₂ supplies and soap bubble flowmeters with a stopwatch for product gas flows.

CO₂ Separation Hardware

The CO₂ separation hardware consisted of a five-cell electrochemical module and its associated test stand and data acquisition hardware.

Electrochemical Module Hardware

Existing EDC module components formed the basis for the EOSM hardware. These components were modified consistent with the operational requirements of an ECSM. Primary emphasis was placed on supplying proper materials for current collection and for the unitized cell cores. Each of the latter consisted of two gas cavity spacers, an anode, a cathode and the cell separating material molded into a single unit. Table 2 lists characteristics of key cell components for the EOSM.

The full size 0.5 ft² cell hardware consisted of injection molded polysulfone frames with an integral liquid coolant compartment. A combination of silver and tantalum current collectors and current distribution tabs were used. Glass filled polysulfone end plates and cast aluminum inlet and exit air manifolds completed the ECSM construction. Each unitized cell core of the ECSM was charged with LSI-D, a Life Systems proprietary electrolyte used for electrochemical CO₂ removal cells. Vacuum charging was employed using a Life Systems electrolyte charging fixture. The five electrochemical cells were arranged to provide for parallel air flow through all five cells and a parallel collection of the cathode product gas.




FIGURE 5 EOSM TEST SETUP MECHANICAL SCHEMATIC WITH SENSORS

10/23/96

LEGEND






























	VALVE, MANUAL SHUT OFF (OPEN)
	VALVE, ELECTRICAL SHUTOFF (NORMALLY CLOSED)
	ORIFICE, VARIABLE (MANUAL)
	REGULATOR, BACK PRESSURE WITH MANUAL ADJ.
	VALVE, ELECTRICAL DIVERTER
	VALVE, MANUAL THREE-WAY
	PUMP
	BLOWER
	HEAT EXCHANGER
	SENSOR, DEW POINT
	SENSOR, TEMPERATURE
	SENSOR, LEVEL
	SENSOR, PRESSURE
	SENSOR, VOLTAGE
	SENSOR, CURRENT
	FLOW METER WITH FLOW CONTROL
	ACCESS PORT, CAPPED
	VALVE, CHECK
	FILTER
	GAUGE, PRESSURE
	ACCUMULATOR (MECHANICAL)
	HEATER, ELECTRICAL
	VALVE POSITION INDICATOR, ELECTRICAL
	COOLING COIL
	ORIFICE, FIXED
	LINE, GAS
	LINE, LIQUID
	LINE, ELECTRICAL
	MAINTAINABLE UNIT BOUNDARY

Figure 5 - continued




FIGURE 6 EOSM DATA ACQUISITION SYSTEM

TABLE 2 ECS CELL COMPONENT CHARACTERISTICS

<u>Component</u>	<u>Material</u>	<u>Thickness, in</u>
Cathode Gas Cavity Spacer	Ni Exmet	0.085
Cathode Electrode	Noble Metal Catalyst on Ni Screen	0.012
Matrix	Mineral-based	0.030
Anode Electrode	Metal Oxides on Porous Ti Plaque	0.040
Anode Gas Cavity Spacer	Ti Exmet	0.040

Electrical current was routed to flow in series through the five cells. Liquid coolant passages were arranged to allow for parallel liquid coolant flow, flowing countercurrent to the process air for more uniform temperature gradients.

Test Stand and Data Acquisition Hardware for the ECSM

An existing test stand was modified to allow testing of the five-cell ECSM. Figure 7 shows a schematic of the ECSM test stand while Figure 8 shows the associated ECSM data acquisition system.

The ECSM test stand provided for the capability to vary air flow rate, air relative humidity and air partial pressure of CO₂. In addition, a feedback controlled liquid coolant loop to control module temperature was included. Various valves, flow meters and pressure regulators were used to allow for maintaining desired fluidic conditions while sampling influent and effluent gas streams of the module.

The electrical hardware included the capability to select and maintain module current levels while monitoring individual cell and module voltages. Shutdown protection for high cathode exit air back pressure as well as for low cell voltages was incorporated. Exceeding setpoints automatically configured the system into a safe mode.

The analytical instruments and data acquisition hardware included two Lira 3000 CO₂ analyzers, one to measure the low range of pCO₂ in the inlet and exit of the process air stream, the second to measure the high levels of pCO₂ in the effluent cathode exhaust stream. Again, a Molytek multi-channel data logger was used to record key module and test stand parameters.

Integrated APC Hardware

Following the completion of the individual module testing, the modules were inspected to see if refurbishment was required. Test stand modifications were incorporated to allow integrated APC operation and data collection system.

Electrochemical Modules


Following the individual module tests both the EOSM and ECSM were removed from their respective test stands, partially disassembled, inspected and reassembled. No modifications or corrections were required.

Test Stands and Data Acquisition Hardware for the APC

The two module test stands were modified at their interfaces to allow sending the anode effluent O₂ and CO₂ mixture from the ECSM directly to the inlet of the EOSM. A variety of other interfaces were capped off since they were not used during integrated operation. The resulting schematics of the ECSM and EOSM sections of the integrated APC test stand are

10/23/96

FIGURE 7 EC5M TEST SETUP MECHANICAL SCHEMATIC WITH SENSORS



LEGEND






























	VALVE, MANUAL SHUT OFF (OPEN)
	VALVE, ELECTRICAL SHUTOFF (NORMALLY CLOSED)
	ORIFICE, VARIABLE (MANUAL)
	REGULATOR, BACK PRESSURE WITH MANUAL ADJ.
	VALVE, ELECTRICAL DIVERTER
	VALVE, MANUAL THREE-WAY
	PUMP
	BLOWER
	HEAT EXCHANGER
	SENSOR, DEW POINT
	SENSOR, TEMPERATURE
	SENSOR, LEVEL
	SENSOR, PRESSURE
	SENSOR, VOLTAGE
	SENSOR, CURRENT
	FLOW METER WITH FLOW CONTROL
	ACCESS PORT, CAPPED
	VALVE, CHECK
	FILTER
	GAUGE, PRESSURE
	ACCUMULATOR (MECHANICAL)
	HEATER, ELECTRICAL
	VALVE POSITION INDICATOR, ELECTRICAL
	COOLING COIL
	ORIFICE, FIXED
	LINE, GAS
	LINE, LIQUID
	LINE, ELECTRICAL
	MAINTAINABLE UNIT BOUNDARY

Figure 7 - continued




FIGURE 8 ECSM DATA ACQUISITION SYSTEM

shown in Figures 9 and 10, respectively. Figure 11 shows the APC data acquisition system using both high and low range pCO₂ Lira analyzers, soap bubble flowmeters for accurate gas measurements and the Molytek multichannel data logger. Figure 12 is a photograph of the integrated test setup used for APC testing.





FIGURE 9 ECSM TEST SETUP MECHANICAL SCHEMATIC WITH SENSORS FOR INTEGRATED APC OPERATION

04/28/97



27

FIGURE 10 EOSM TEST SETUP MECHANICAL SCHEMATIC WITH SENSORS
FOR INTEGRATED APC OPERATION

04/28/97




FIGURE 11 APC DATA ACQUISITION SYSTEM




FIGURE 12 APC INTEGRATED TEST SETUP

TEST PROGRAM

An overall test program was defined based on the test objectives. A test sequence was established initially testing at the individual module level, followed by integrated APC testing.

Test Objectives

The test objectives were two-fold. First, to test individually the modules, to establish test conditions and module operating characteristics that would allow for eventual integrated APC testing; and secondly, to obtain test data to allow sizing of a full sized (four person capacity) APC for CO₂ removal from low pCO₂ atmospheres.

These objectives were met by first testing the five-cell EOSM for various simulated ECSM anode effluent flow rates and O₂ to CO₂ mixture ratios, followed by testing a five cell ECSM for various ranges in processor air inlet conditions. Sizing data for an APC system was derived from data obtained during both the integrated APC as well as the individual testing of the two five-cell electrochemical modules.

Selection and Definition of Initial Test Conditions

Selection of nominal operating conditions for the two modules was performed as an iterative process requiring consideration of key parameters such as dewpoints, temperatures, module electrical performance, CO₂ removal efficiency, electrolyte characteristics and module current levels. The output of this effort resulted in the nominal operating conditions for the EOSM and ECSM as shown in Tables 3 and 4, respectively. Vapor pressures of the two electrolytes i.e., H₃PO₄ as well as LSI-D, for the EOSM and ECSM, respectively, were investigated to determine proper moisture interaction of the gas flows from one module to the other. Vapor pressure versus temperature for these two electrolytes are shown in Figures 13 and 14, respectively.

The CO₂ removal efficiency of the ECSM determines the cathode feed gas composition for the EOSM. In order to characterize this interface, the curves shown in Figure 15 were prepared which show the percent of O₂ and CO₂ in the anode vent gas from the ECSM as a function of the ECSM's CO₂ removal efficiency. A nominal design point of a 60% CO₂ removal efficiency at a pCO₂ of 2.3 mm Hg, was initially selected and used to prepare Tables 3 and 4. This efficiency resulted in a nominal 45% O₂ and 55% CO₂ cathode feed gas mixture to the EOSM. As shown in Figure 15, subsequent ECSM testing showed higher than 60% efficiencies were achievable. As a result, the operating conditions were subsequently adjusted to a 75% efficiency, as discussed in the ECSM and APC test sections.

Since the EOSM has its cathode compartments connected fluidically in series to enhance removal of the O₂ from the mixture of O₂ and CO₂ feed gas, the outlet of an upstream cell constitutes the inlet conditions for a downstream cell, and so on. For reference, the conditions at each of the five EOSM cell inlets and outlets were calculated. The results are shown in Table 5 which shows the flow rates of O₂ and CO₂ for a variety of ECSM CO₂

TABLE 3 INITIAL FIVE-CELL ELECTROCHEMICAL OXYGEN SEPARATION
MODULE (EOSM) OPERATING PARAMETERS

	<u>Nominal</u>
Current	
Level, A	6.0
% of ECSM, %	75
Module Temp, F	83
Cathode Feed	
Flow Rate, sccm	311
Composition, % O ₂ / % CO ₂	45/55 ^(a)
Stoichiometric Ratio	1.33
Temperature, F	72
Dewpoint, F	67
Pressure (outlet), psig	1.0
Coolant	
Flow Rate, lb/hr	50
Temperature, F	82
Anode Vent Pressure, psig	0

(a) Equivalent to 60% Electrochemical Carbon Dioxide Separation Module (ECSM) carbon dioxide (CO₂) removal efficiency at 2.3 mm Hg pCO₂ in air feed stream (140 sccm of oxygen (O₂) and 171 sccm CO₂).

TABLE 4 INITIAL FIVE-CELL ELECTROCHEMICAL CARBON DIOXIDE
SEPARATION MODULE (ECSM) OPERATING PARAMETERS

	<u>Nominal</u>
Current, A	8.0
Module Temp, F	83
Cathode Air	
Flow Rate, ACFM	9.0
pCO ₂ , mm Hg	2.3
Pressure, psia	15
Temperature, F	75
Dewpoint, F	63
RH, %	64
Coolant	
Flow Rate, lb/hr	50
Temperature, F	82
Anode Vent	
Pressure, psig	1.0
O ₂ Flow, sccm	140
CO ₂ Flow, sccm	171 ^(a)

(a) A total of 171 sccm carbon dioxide (CO₂) at the projected CO₂ removal efficiency of 60% for a 2.3 mm Hg pCO₂ in the ECSM Cathode Air Feed Stream.




FIGURE 13 WATER VAPOR PRESSURE FOR AQUEOUS H_3PO_4




FIGURE 14 WATER VAPOR PRESSURE OF LSI-D ELECTROLYTE




FIGURE 15 ECSM ANODE VENT GAS COMPOSITION AS A FUNCTION OF CO₂ REMOVAL EFFICIENCY

TABLE 5 FIVE-CELL CARBON DIOXIDE (CO₂) CONCENTRATING PROCESS

ECSM CO ₂ Removal Efficiency, %	EOSM Cell Compartment ^(b)	Flow Rate, sccm O ₂ /CO ₂ ^(a)										
		Cell No. 1		Cell No. 2		Cell No. 3		Cell No. 4		Cell No. 5		
		In	Out	In	Out	In	Out	In	Out	In	Out	
36	0	C	140/0	119/0	119/0	98/0	98/0	77/0	77/0	56/0	56/0	35/0
		A	0/0	21/0	21/0	42/0	42/0	63/0	63/0	84/0	84/0	105/0
	20	C	110/57	119/57	119/57	98/57	98/57	77/57	77/57	56/57	56/57	35/57
		A	0/0	21/0	21/0	42/0	42/0	63/0	63/0	84/0	84/0	105/0
	40	C	140/110	119/110	119/110	98/110	98/110	77/110	77/110	56/110	56/110	35/110
		A	0/0	21/0	21/0	42/0	42/0	63/0	63/0	84/0	84/0	105/0
	60	C	140/170	119/170	119/170	98/170	98/170	77/170	77/170	56/170	56/170	35/170
		A	0/0	21/0	21/0	42/0	42/0	63/0	63/0	84/0	84/0	105/0
	80	C	140/228	119/228	119/228	98/228	98/228	77/228	77/228	56/228	56/228	35/228
		A	0/0	21/0	21/0	42/0	42/0	63/0	63/0	84/0	84/0	105/0
	100	C	140/284	119/284	119/284	98/284	98/284	77/284	77/284	56/284	56/284	35/284
		A	0/0	21/0	21/0	42/0	42/0	63/0	63/0	84/0	84/0	105/0

(a) For a current of 8A through the ECSM and 6A through the EOSM.

(b) C = Cathode Compartment, A = Anode Compartment.

10/15/96

removal efficiencies. This table was prepared for the initial nominal current levels of 6.0 Amps and 8.0 Amps for the EOSM and ECSM, respectively. These current levels were selected from previous data^(3,4).

The nominal inlet air relative humidity for the ECSM was selected to be 64%, representative of a dry bulb temperature of 75 F and a dewpoint temperature of 63 F, as indicated on Figure 16. To control the module temperatures, a requirement of 50 lb/hr of 82 F liquid (water) coolant was calculated and was supplied by the test stands to each of the two modules.

Electrochemical O₂ Separation Testing

Using the previously established test operating conditions (see Table 3) a test sequence was defined and testing of the EOSM completed.

EOSM Test Sequence

The test sequence established and completed for the EOSM was as follows:

1. Checkout testing
2. Shakedown testing
3. Design verification testing
4. Parametric testing

The various parameter ranges of cathode feed, currents and coolant flows and remarks for these four test phases are shown in Appendix A, Tables A-1 through A-4, respectively. A data sheet for the EOSM testing was prepared for the four test phases and is shown in Appendix B, Figure B-1.

EOSM Test Results

Test results for the individual EOSM testing are shown in Figures 17 through 20. These results were also compared to past test data obtained with a two cell module.^(3,5) These comparisons are plotted in Figures 21 and 22. The nominal operating condition for the EOSM are indicated on each of the figures. The results compare well with the previous data, indicating that scaling to the five-cell module level did not cause loss in performance.

The EOSM data was analyzed and reduced. The analysis concentrated on identifying any changes in nominal operating conditions for integrated APC operation. Slight changes in module temperature levels, dewpoints and ECSM electrolyte concentration resulted to allow for a closer match for integrated operation. The changes are discussed in the next section under ECS Testing.

Two other aspects of EOSM operation were analyzed due to their importance with respect to future integrated system operation and efficient performance. These parameters are




FIGURE 16 NOMINAL INLET AIR HUMIDITY CONDITIONS USED FOR APC TESTS

10/23/96




FIGURE 17 EFFECT OF CURRENT ON EOSM CELL VOLTAGE WITH PURE O₂ FEED

10/30/96




FIGURE 18 EFFECT OF CURRENT ON EOSM CELL VOLTAGE WITH $54 \pm 2\%$ CO₂ IN FEED

02/03/97




FIGURE 19 EOSM CELL VOLTAGE AND CO₂ COMPOSITION IN THE EOSM OUTLET
VERSUS EOSM TO ECSM CURRENT PERCENTAGE

02/03/97




FIGURE 20 EFFECT OF VARIABLE CO₂ IN EOSM FEED STREAM ON EOSM CELL VOLTAGE

02/03/97




FIGURE 21 COMPARISON OF EFFECT OF CELL CURRENT ON EOSM CELL VOLTAGE WITH PURE O₂ WITH PREVIOUS DATA

10/30/96




FIGURE 22 COMPARISON OF EOSM CELL VOLTAGE AND CO₂ COMPOSITION IN THE EOSM OUTLET VERSUS EOSM CURRENT WITH PREVIOUS DATA

10/29/96

electrochemical current efficiency of the EOSM, i.e., the amount of O₂ transferred on a per coulomb basis as well as the lowest stoichiometric level of cathode feed gas that can be sustained. The latter defines how much of the O₂ contained in the O₂ and CO₂ mixture can be removed by the EOSM resulting in the lowest remaining O₂ to be fed to a CO₂ reduction process, i.e., a Sabatier or Bosch, where the O₂ would combine with H₂ to form water for re-electrolization.

A 100% O₂ theoretical transfer efficiency is equal to 3.48 standard (at 32 F, 760 mm Hg) cm³/min of O₂ for each cell-ampere flowing. For example, for a five-cell module operating at 8 A the theoretical anode output in O₂ is equivalent to 139.2 standard cm³ of O₂/min. Based on this calculation, all data points accumulated during the EOSM operation were reduced resulting in a range of O₂ transfer efficiencies from 93.4 to 102.3%. The average transfer efficiency for all data points was 99.8%. Based on these actual test results, within the accuracy of the measuring instrumentation, a 99.5% transfer efficiency will be assumed in future EOSM sizing of an integrated APC.

During the current density spans, while operating with 54±2% of CO₂ in the cathode feed, the stoichiometry of the feed gas was varied from 2.54 to 1.02. A stoichiometric feed value of 1.00 would result theoretically in all of the O₂ supplied to the cathode compartments being transferred to the anode compartments of an EOSM. For a stoichiometric feed value of 1.00 no O₂ would be left in the cathode exhaust gas. A goal in APC operation is to have as little as possible O₂ left, meaning operation close to a 1.00 stoichiometric feed rate is desirable. Actual operation at a 1.02 stoichiometric feed rate was achieved with steady conditions indicating that efficient gas mixing and flow distribution occurred within the five serially connected EOSM cells. A conservative value of 1.05 (95% of all O₂ fed to the EOSM will be transferred back to the atmosphere) was selected for integrated APC sizing.

The five-cell EOSM module was disassembled for visual inspection to see if any anomalies had resulted from the test phase completed. No unusual observations were made and the module was reassembled for integrated APC testing.

Electrochemical CO₂ Separation Testing

Test conditions for the ECSM testing were evaluated and adjusted as required, based on EOSM testing. A test sequence was defined and testing of the five-cell ECSM was completed.

ECSM Test Condition Verification

Based on the EOSM test results, slight adjustments to the nominal operating conditions previously shown in Tables 3 and 4 were made. These new conditions are represented in Tables 6 and 7, for the ECSM and EOSM, respectively. The differences are minor reflected in a decrease in module nominal operating temperatures for both modules from 83 to 80 F and a lowering of the cathode gas nominal inlet dewpoint to the EOSM from 67 to 63 F. These adjustments were made to match the characteristics of the anode vent gas of the ECSM

TABLE 6 FIVE-CELL ELECTROCHEMICAL CARBON DIOXIDE SEPARATION
MODULE (ECSM) OPERATING PARAMETERS

	<u>Nominal</u>
Current, A	8.0
Module Temp, F	80
Cathode Air	
Flow Rate, ACFM	15 ^(a)
pCO ₂ , mm Hg	2.3
Pressure, psia	15
Temperature, F	75
Dewpoint, F	63
RH, %	64
Coolant	
Flow Rate, lb/hr	50
Temperature, F	80
Anode Vent	
Pressure, psig	1.0
O ₂ Flow, sccm	140
CO ₂ Flow, sccm	171 ^(b)

(a) Nominal range of 12 to 18 ACFM.

(b) A total of 171 sccm carbon dioxide (CO₂) at the projected CO₂ removal efficiency of 60% for a 2.3 mm Hg pCO₂ in the ECSM Cathode Air Feed Stream.

TABLE 7 FIVE-CELL ELECTROCHEMICAL OXYGEN SEPARATION MODULE
(EOSM) OPERATING PARAMETERS

	<u>Nominal</u>
Current	
Level, A	6.0
% of ECSM, %	75
Module Temp, F	80
Cathode Feed	
Flow Rate, sccm	311
Composition, % O ₂ / % CO ₂	45/55 ^(a)
Stoichiometric Ratio	1.33
Temperature, F	72
Dewpoint, F	63
Pressure (outlet), psig	1.0
Coolant	
Flow Rate, lb/hr	50
Temperature, F	80
Anode Vent Pressure, psig	0

(a) Equivalent to 60% Electrochemical Carbon Dioxide Separation Module (ECSM) carbon dioxide (CO₂) removal efficiency at 2.3 mm Hg pCO₂ in air feed stream (140 sccm of oxygen (O₂) and 171 sccm CO₂).

with its 65% w/w electrolyte cell core concentration. Initially a 56% w/w LSI-D electrolyte concentration was contemplated, but based on the EOSM performance a higher ECSM electrolyte concentration was selected as a better match. The nominal inlet air humidity conditions to be used for the ECSM and integrated APC testing remain the same as was shown in Figure 16. The air flowrate through the ECSM was adjusted from a nominal 9 ACFM to 15 ± 3 ACFM to allow for better (more constant) test stand air flow control.

ECSM Test Sequence

The test sequence established and completed for the ECSM and used was as follows:

1. Checkout testing
2. Shakedown testing
3. Design verification testing
4. Parametric testing

The various parameter ranges of cathode feed air, current levels and coolant flows and remarks for these four test phases are shown in Appendix A, Tables A-5 through A-8, respectively. A two page set of data sheets used for the ECSM testing was prepared for the four test phases. The data sheets are shown in Appendix B, Figure B-2.

ECSM Test Results

Test results for the ECSM testing are shown in Figures 23 through 31. These results were also compared to past test data obtained with a two cell module.^(3,5) This comparison is plotted in Figure 32. The operating condition for the ECSM are indicated on each plot. As can be seen from Figure 32, the present results compare well with past performance, indicating that scaling to the approximately one person, five-cell module did not adversely affect performance.

Effects of Module Current Density. The effects of current density over the range of 6 to 20 ASF (3 to 10 A) were investigated for the ECSM for nominal inlet air $p\text{CO}_2$ values of 0.3 mm Hg, 1.25 mm Hg, 2.2 mm Hg and 3.6 mm Hg. Figures 23 through 26 show the effects of current density on average ECSM cell voltage for the four $p\text{CO}_2$ levels listed above. As expected, cell voltage increases with increasing current density resulting in higher power consumption at higher currents. Also, a slight decreasing effect in average ECSM cell voltage is observed with increasing $p\text{CO}_2$. These results are similar to those typically observed with electrochemical CO_2 removal cells.

Figures 27 through 30 show the effect of current density over the same current ranges and the other key parameter of ECSM operation i.e., CO_2 removal efficiency. Historically^(1,3,7) CO_2 removal efficiency reaches a peak value from 15 to 25 ASF. The same results were observed at each of the four $p\text{CO}_2$ levels tested. A sharper drop off at lower current densities in CO_2 removal efficiencies compared to those observed with an EDC were experienced with




FIGURE 23 EFFECT OF CURRENT ON ECSM CELL VOLTAGE (AIR INLET pCO₂ - 0.3 mm Hg)




FIGURE 24 EFFECT OF CURRENT ON ECSM CELL VOLTAGE (AIR INLET pCO₂ - 1.25 mm Hg)

01/16/97




FIGURE 25 EFFECT OF CURRENT ON ECSM CELL VOLTAGE (AIR INLET pCO₂ - 2.2 mm Hg)

01/16/97




FIGURE 26 EFFECT OF CURRENT ON ECSM CELL VOLTAGE (AIR INLET pCO₂ - 3.6 mm Hg)




FIGURE 27 EFFECT OF CURRENT ON ECSM CO₂ TRANSFER EFFICIENCY (AIR INLET pCO₂ - 0.3 mm Hg)

05/31/97




FIGURE 28 EFFECT OF CURRENT ON ECSM CO₂ TRANSFER EFFICIENCY (AIR INLET pCO₂ - 1.25 mm Hg)

05/31/97




FIGURE 29 EFFECT OF CURRENT ON ECSM CO₂ TRANSFER EFFICIENCY (AIR INLET pCO₂ - 2.2 mm Hg)

05/31/97




FIGURE 30 EFFECT OF CURRENT ON ECSM CO₂ TRANSFER EFFICIENCY (AIR INLET pCO₂ - 3.6 mm Hg)

05/31/97




FIGURE 31 ECSM CELL VOLTAGE AND CO₂ TRANSFER EFFICIENCY VERSUS INLET AIR pCO₂ AT NOMINAL CELL CURRENT OF 8.0 A




FIGURE 32 COMPARISON OF ECSM CELL VOLTAGE AND CO₂ TRANSFER EFFICIENCY VERSUS CURRENT DENSITY WITH PAST DATA

01/16/97

an ECSM. Overall system sizing and final operating condition selection will be influenced by this observation.

Effects of ECSM Inlet Air pCO₂. The data obtained during the current density span testing was cross plotted at 8 A to determine the effects of pCO₂ on the key parameters of an ECSM: CO₂ transfer efficiency and average cell voltage. Figure 31 shows these key ECSM parameters versus pCO₂ in the cathode feed air. As expected, CO₂ transfer efficiency is a strong function of air inlet pCO₂, but achieves a near constant value at and beyond the 2 mm Hg pCO₂ level. The shape and levels observed compare well with historical data for electrochemical CO₂ removal systems.⁽³⁾

Cell voltage is a weak function of inlet air pCO₂ as shown in the lower part of Figure 31. Historically, a slight decrease in cell voltage with increasing pCO₂ has been observed. The current data shows this trend. Voltage levels are consistent with past data obtained for the test conditions shown for H₂-less electrochemical CO₂ removal cells.^(3,5)

Integrated APC Testing

Based on an analysis of the ECSM and EOSM test results, the operating conditions for both modules were re-evaluated to identify if any final adjustments were required for integrated APC Testing. The APC test sequence was then established, all APC testing completed and the results analyzed. A summary of characteristics for APC sizing was prepared.

Adjustment of Test Conditions

Based on the ECSM test results, only slight adjustments to the nominal operating conditions were necessary. These final conditions are shown in Tables 8 and 9 for the ECSM and EOSM, respectively. The differences are reflected in an increase in CO₂ in the effluent from the ECSM cathode compartments due to the higher CO₂ removal efficiencies achieved (nominal 75% versus 60%) for the properly tuned ECSM. A decrease in nominal air flow rate to 10±1 scfm (equivalent to 2 scfm per cell) was selected based on minor test stand modifications that allowed for better air flow control. Nominal air inlet relative humidity remained the same at 64%.

APC Test Sequence

The test sequence established and completed for the APC was as follows:

1. Checkout testing
2. Shakedown testing
3. Design verification testing
4. Parametric testing

The various parameter ranges of APC cathode feed air, CO₂ levels, current levels and coolant flows and remarks for these four test phases are shown in Appendix A, Tables A-9 through

TABLE 8 FIVE-CELL ELECTROCHEMICAL CARBON DIOXIDE SEPARATION
MODULE (ECSM) OPERATING PARAMETERS

	<u>Nominal</u>
Current, A	8.0
Module Temp, F	80
Cathode Air	
Flow Rate, ACFM	10 ^(a)
pCO ₂ , mm Hg	2.3
Pressure, psia	15
Temperature, F	75
Dewpoint, F	63
RH, %	64
Coolant	
Flow Rate, lb/hr	50
Temperature, F	80
Anode Vent	
Pressure, psig	1.0
O ₂ Flow, sccm	140
CO ₂ Flow, sccm	210 ^(b)

(a) Nominal range of 9 to 11 ACFM.

(b) A total of 210 sccm carbon dioxide (CO₂) at the projected CO₂ removal efficiency of 75% for a 2.3 mm Hg pCO₂ in the ECSM Cathode Air Feed Stream.

TABLE 9 FIVE-CELL ELECTROCHEMICAL OXYGEN SEPARATION MODULE
(EOSM) OPERATING PARAMETERS

	<u>Nominal</u>
Current	
Level, A	6.0
% of ECSM, %	75
Module Temp, F	80
Cathode Feed	
Flow Rate, sccm	350 ^(a)
Composition, % O ₂ / % CO ₂	40/60 ^(b)
Stoichiometric Ratio	1.33
Temperature, F	72
Dewpoint, F	63
Pressure (outlet), psig	1.0
Coolant	
Flow Rate, lb/hr	50
Temperature, F	80
Anode Vent Pressure, psig	0

(a) Equivalent to 75% Electrochemical Carbon Dioxide Separation Module (ECSM) carbon dioxide (CO₂) removal efficiency at 2.3 mm Hg pCO₂ in air feed stream (140 sccm of oxygen (O₂) and 210 sccm CO₂).

A-12, respectively. A three page set of data sheets for the APC testing was prepared for the four test phases. The data sheets are shown in Appendix B, Figure B-3.

APC Test Results

Test results and/or conditions for the integrated APC testing are shown in Figures 33 through 40. The operating condition for the ECSM or EOSM of the integrated APC are indicated on each plot. Analysis and discussion of the APC test data obtained for variations in APC inlet air $p\text{CO}_2$, inlet air relative humidity and current densities (for both modules) are presented below.

Effects of APC Inlet Air $p\text{CO}_2$. The effects of the $p\text{CO}_2$ level of the inlet air supplied to the APC was investigated for four nominal values: 0.3 mm Hg (ambient air level), 1.0 mm Hg, 2.2 mm Hg and 3.0 mm Hg. All other parameters were held nominally at the values as reflected in Tables 8 and 9.

Figure 33 shows the key APC parameters, i.e., CO_2 transfer efficiency and average cell voltage of the ECSM versus the CO_2 partial pressure in the cathode feed air. As expected, CO_2 transfer efficiency is a strong function of inlet air $p\text{CO}_2$, but achieves a near constant value at and beyond the 1.0 mm Hg $p\text{CO}_2$ level. The shape and levels observed compare well with historical data for electrochemical CO_2 removal systems.⁽³⁾

Cell voltage is a very weak function of inlet air $p\text{CO}_2$, as shown in the lower part of Figure 33. Historically, a slight decrease in cell voltage with increasing $p\text{CO}_2$ has been observed. The current data shows this trend beyond the 2.0 mm $p\text{CO}_2$ level. Voltage levels are consistent with past data obtained for the test conditions shown and for H_2 -less electrochemical CO_2 removal cells.^(3,5)

Effects of APC Inlet Air Relative Humidity. Three regions of inlet relative humidity of the process air were explored: (1) Above i.e., slightly wetter, than the nominal ECSM air inlet humidity range; (2) hot and dry; and (3) cold and dry. The latter two are the more difficult inlet relative humidities to accommodate and therefore were chosen to challenge the integrated APC. Figure 34 shows these three regions, indicated by shaded areas, together with the nominal ECSM air inlet relative humidity point.

Figure 35 plots CO_2 transfer efficiency as a function of air inlet relative humidity over a 40 to 80% range. The figure indicates, by vertical bars, the general range in CO_2 removal efficiencies achieved. A trend of a slight increase in CO_2 transfer efficiency with increasing relative humidity is noted. This slight increase is due to the generally higher operating temperatures characteristic of the higher RH values chosen.

Similarly, ECSM average cell voltage as a function of inlet air relative humidity is plotted in Figure 36. As expected, a slight decrease in cell voltage is observed at the higher relative humidity values, again, due to the typically higher module operating temperatures




FIGURE 33 APC ECSM CELL VOLTAGE AND CO₂ TRANSFER EFFICIENCY
 VERSUS INLET AIR pCO₂ AT NOMINAL CELL CURRENT OF 8.0 A

05/32/97




FIGURE 34 INLET AIR HUMIDITY CONDITIONS USED FOR APC TESTS

04/28/97




FIGURE 35 EFFECT OF AIR INLET RELATIVE HUMIDITY ON APC CO₂ TRANSFER EFFICIENCY
 (AIR INLET pCO₂ = 2.2 mm Hg)

04/28/97




FIGURE 36 EFFECT OF AIR INLET RELATIVE HUMIDITY ON APC ECSM CELL VOLTAGE
(AIR INLET $p\text{CO}_2 = 2.2$ mm Hg)

04/28/97




FIGURE 37 APC ECSM CO₂ TRANSFER EFFICIENCY VERSUS CELL CURRENT FOR SELECTED CO₂ INLET COMPOSITIONS

04/28/97




FIGURE 38 EFFECT OF CURRENT ON APC ECSM CELL VOLTAGE

12/20/96





FIGURE 39 EFFECT OF CURRENT ON APC EOSM CELL VOLTAGE

04/28/97

FIGURE 40 EOSM CURRENT EXPRESSED AS PERCENTAGE OF EC5M CURRENT



characteristic of higher relative humidities. Lower voltages are desirable, since they are representative of lower power requirements.

Effects of Module Current Densities. The effects of current density over the range of 8 to 20 ASF for the ECSM and 7 to 15 ASF for the EOSM were investigated. Figure 37 shows CO₂ transfer efficiency as a function of ECSM current and current density. As expected⁽³⁾ a slight maximum was reached near the 8 Amp or 16 ASF conditions. The data was taken at a nominal pCO₂ level of 2.2 mm Hg.

Figure 38 shows ECSM average cell voltage as a function of ECSM current and current density. The data compares favorably with past data^(3,5) and shows an increase in cell voltage as a function of increasing current/current density.

The nominal CO₂ transfer efficiency design point was increased from 60 to 75%, based on the integrated testing. As a result, the O₂ to CO₂ mixtures sent to the EOSM will generally range from 40±3% to 60±3%, as was also shown on Figure 15.

Figure 39 shows the effect of EOSM current and current density on EOSM cell voltage. The figure shows typical cell voltage trends as a function of current and current density for the nominal conditions indicated. The results for integrated APC testing were similar to those obtained for the EOSM tests.

The effect of variations in O₂ stoichiometry on EOSM performance was also investigated. The closer the stoichiometric value to 1.0, the less O₂ is sent to a CO₂ reduction subsystem to form water for re-electrolysis. The latter presents a penalty to the system. Stoichiometry can also be expressed as a percentage based on the ratio of the product of EOSM current times its number of cells to the product of ECSM current times its number of cells. For example, 100% is equal to a stoichiometric value of 1.0 a 95% ratio value is equal to 1.053, 90% is equal to 1.111, etc. Figure 40 shows EOSM performance for up to a 98% current level of the ECSM (at an equal number of cells). A nominal value of 95% was selected.

Summary of Electrochemical Characteristics for APC Sizing

Table 10 lists the physical and performance characteristics for sizing of the electrochemical modules for an APC system. The characteristics were based on both the individual module and the integrated APC test results achieved as part of this program. Since both ECSM and EOSM use physically similar cell hardware to that developed by Life Systems for EDC operation, characteristics of EDC cells established for flight hardware have been used in Table 10.

TABLE 10 PHYSICAL AND PERFORMANCE CHARACTERISTICS
FOR ELECTROCHEMICAL MODULE SIZING
FOR APC APPLICATION

	<u>ECSM</u>	<u>EOSM</u>
Nominal Module Current ^(a) , A	8.0	7.5
Cell Voltage, V	1.25	1.20
Stoichiometric O ₂ Flow	N/A	1.053 ^(a)
Cell Characteristics		
Active Area, ft ²	0.5	0.5
Thickness, in	0.4	0.4
Weight, lb	2.2	2.2
CO ₂ Removal Efficiency, %	75	N/A
Air Flow/Cell, SCFM	2.0	N/A
Air Inlet pCO ₂		
mm Hg	2.2	N/A
%	0.29	N/A
Liquid Coolant Flow, lb/hr/cell	10	10

(a) Final minor adjustments to currents will result during APC sizing since fractional cells are not possible.

(b) Based on the inverse of (EOSM Current x EOSM No. of Cells) ÷ (ECSM Current x ECSM No. of Cells) = 0.95.

APC SIZING AND COMPARISONS

Requirements were defined and comparison criteria established to allow for sizing and comparison of an APC with four competitive CO₂ removal technologies. The four competing technologies selected were an Electrochemical Depolarized Concentrator (EDC), a Four-Bed Molecular Sieve (4BMS), a Solid Amine Water Desorbed (SAWD) system and a system based on a non-regenerable technique i.e., Lithium Hydroxide (LiOH). Except for the LiOH based system, all systems must incorporate the required hardware and controls to allow CO₂ to be delivered to a CO₂ reduction system such as a Sabatier or Bosch. The latter requirement eliminated configurations or concepts where CO₂ is vented to space vacuum or where space vacuum is used to desorb CO₂.

Requirements Definition and Comparison Criteria

The atmospheric characteristics with which a CO₂ removal systems must interface were selected based on those typically projected for the Space Station use.⁽¹⁰⁾ These values are presented in Table 11. The CO₂ partial pressures selected for this study were equal to and less than 3 mm Hg. A competing system's size was first determined at the 3 mm Hg level using data from literature, as available, followed by its projection at 2.2 mm Hg. The APC and EDC, of course, were sized based on actual 3.0 mm Hg and 2.2 mm Hg test data.

System sizing and comparison requires also definition of a crew size, i.e., the amount of CO₂ to be removed for a given time period. Literature cites generally CO₂ technologies sized for four-person applications, or equivalent to 8.8 lb of CO₂ for 24 hour period. A four-person CO₂ generation rate was selected. A ten year mission duration was chosen, which is similar to that projected for the International Space Station (ISS).

A common denominator is required for one-to-one comparisons. The common denominator chosen for the CO₂ technologies comparisons was total equivalent weight, consisting of fixed hardware launch weight, weight of expendibles required for a ten year mission, weight penalty for power consumption, weight penalty for heat load rejection, weight penalty for orbit-keeping propulsion and weight penalty for O₂ consumption. The resulting CO₂ removal sizing and comparison criteria are quantified in Table 12. The quantification of weight penalties for various parameters were based on those presented in literature as referenced in Table 12.

While launch volumes for each system were determined and are presented in this report, no easy conversion to equivalent weight could be defined or was available in literature. Hence, the system volume numbers are presented for relative informational purposes only.

The complexity of calculating the weight of spares required based on various reliabilities to meet a ten year life was not incorporated in this system comparison, but is recommended as a follow on activity. As a result, comparisons are made based on the assumption that the system hardware will work properly for the ten year mission duration selected.

TABLE 11 SPACE STATION ATMOSPHERE REQUIREMENTS

Total Pressure, lb/in ²	14.5 - 14.9
Oxygen Partial Pressure, lb/in ²	2.83 - 3.35
Temperature, F	65 - 80
Dew Point Temperature, F	40 - 60
Ventilation Flow Rate, ft/min	15 - 40
CO ₂ Partial Pressure, mm Hg	≤3.0

TABLE 12 CO₂ REMOVAL SYSTEM SIZING AND COMPARISON CRITERIA

Atmosphere Requirements	See Table 11
Crew Size	4
CO ₂ Removal Rate, lb/day	8.8
Mission Duration, Years	10
Power Penalty, lb/W	0.79 ^(a)
Heat Load Penalty, lb/W	0.24 ^(a)
Propulsion Penalty, lb/W	0.06 ^(a)
O ₂ Consumption Penalty, lb/lb O ₂ /day	82.2 ^(b)

(a) See Ref. No. 11.

(b) Based on data presented in Ref. Nos. 8 and 12.

APC System and Definition Sizing

Based on the requirements and criteria established above, a four-person capacity CO₂ removal system based on APC technology was defined and sized. The results are presented in Table 13 summarizing detailed characteristics of the ECS module, the EOS module, ancillary components and a summation of characteristics for the total system at the two pCO₂ levels indicated.

A summary of the benefits of a APC based CO₂ removal system are:


- The APC operates continuously (versus cyclically), i.e., removes CO₂ continuously to help maintain the level of CO₂ in the cabin atmosphere more uniformly than any cyclically operating system.
- The rate of CO₂ removal can be controlled by varying operating parameters such as cell current, air flow rate, etc.
- It operates at near ambient temperature and pressure, resulting in minimum thermal losses and simple transition operations.
- The capacity of the system can be easily varied for different missions by adding or reducing the number of electrochemical cells in the cell modules.
- The APC does not require any expendables or regeneration process, resulting in low power consumption, weight and volume requirements.

Alternate CO₂ Removal Systems Definition and Sizing

The same requirements and sizing criteria established for the APC were used to define and size the four alternate systems, an EDC, a 4BMS, a SAWD and a LiOH based system.

Electrochemical Depolarized CO₂ Concentrator Technology

The EDC technology, which also has been developed at Life Systems,^(7,8,9,13) is based on the same technology as the ECS portion of the APC with the exception that H₂ is used at the anode. The electrochemical process that occurs at the cathode of the EDC is identical to the electrochemical process occurring at the cathode of the ECS, namely CO₂ from the cabin atmosphere reacts with OH⁻ ions electrochemically generated within a porous gas diffusion cathode according to the following half-cell reaction:



The CO₂ reacts with the OH⁻ and is then transferred within the aqueous alkaline carbonate electrolyte from the cathode (atmosphere side) to the anode (CO₂ concentrating side). The

TABLE 13 PROJECTED PHYSICAL AND OPERATIONAL CHARACTERISTICS OF
THE AIR-POLARIZED CO₂ CONCENTRATOR

Operating Cycle	: Continuous
Capacity	: Four-Person
Inlet pCO ₂ , mm Hg	: 3.0 and 2.2
Cabin Temperature	: 65 to 80
Cabin Pressure, psia	: 14.7
Dewpoint, F	: 40 to 60

<u>ECS Module:</u>	<u>pCO₂ = 3.0 mm Hg</u>	<u>pCO₂ = 2.2 mm Hg</u>
Air Flow Rate, acfm	: 62	68
O ₂ Transferred, lb/day	: 4.10	4.27
No. of Cells	: 31	34
Active Cell Area, ft ²	: 0.50	0.50
Current Density, ASF	: 16.8	15.9
Cell Voltage, V	: 1.25	1.25
Power, W	: 312	324
Weight, lb	: 95	102
Volume, ft ³	: 2.58	2.77
Heat Rejection, W	: 221	230

<u>EOS Module:</u>		
O ₂ Delivered to Cabin, lb/day	: 3.90	4.06
No. of Cells	: 31	34
Active Cell Area, ft ²	: 0.5	0.50
Current Density, ASF	: 15.9	15.1
Cell Voltage, V	: 1.20	1.20
Power, W	: 296	308
Weight, lb	: 95	102
Volume, ft ³	: 2.58	2.77
O ₂ Delivered for CO ₂ reduction, lb/day	: 0.20	0.21
Heat Rejection, W	: 197	205


continued-

Table 13 - continued


<u>Ancillary Components:</u> ^(a)	<u>pCO₂ = 3.0 mm Hg</u>	<u>pCO₂ = 2.2 mm Hg</u>
Power, W	: 55	55
Weight, lb	: 47	47
Volume, ft ³	: 1.42	1.42
Heat Rejection, W	: 55	55
<u>Total System:</u>		
Power, W	: 735 ^(b)	763 ^(c)
Weight, lb	: 238	252
Volume, ft ³	: 6.56	6.96
Heat Rejection, W	: 545 ^(b)	566 ^(c)
O ₂ Penalty ^(d) , lb/day	: 0.20	0.21
Expendable, lb/10 years	: None	None

- (a) Includes fluids and coolant control assemblies, current controllers, heat exchangers, valves, air ducts, etc., for the overall APC System.
- (b) Includes 72 W for power conditioning losses.
- (c) Includes 76 W for power conditioning losses.
- (d) That which is converted to water in a CO₂ reduction subsystem and must be re-electrolyzed.


CO₂ transfer occurs via CO₃⁻² and HCO₃⁻ ions generated from the reaction of CO₂ with OH⁻ according to Reactions 12a and 12b, respectively:



Reaction 12b occurs instantaneously, so Reaction 12a is the rate-determining step. Therefore, the conversion of CO₂ to CO₃⁻² can be described by a single step as shown in Reaction 13:




When the concentration of OH⁻ is depleted, additional CO₂ can be absorbed by:




combining Equation 13 and 14 results in an overall absorption reaction of:




The CO₃⁻² and HCO₃⁻ ions formed at the cathode by Reactions 13 and 15, respectively, migrate toward the anode due to an electrical potential difference applied to the cell.



and



Combining Equations 1, 13 and 16a results in:



While combining Equations 1, 15 and 16b results in:



The anode gas stream is a mixture of CO₂, excess H₂ and water vapor, which can be sent to CO₂ reduction processes such as the Sabatier or Bosch processors.

A block diagram of the electrochemical depolarized CO₂ concentration process is shown in Figure 41. The projected physical and operational characteristics of an EDC CO₂ removal system are shown in Table 14 at the two pCO₂ levels indicated.




FIGURE 41 BLOCK DIAGRAM OF EDC CO₂ REMOVAL SYSTEM

TABLE 14 PROJECTED PHYSICAL AND OPERATIONAL CHARACTERISTICS OF THE ELECTROCHEMICAL DEPOLARIZED CO₂ CONCENTRATOR (EDC)

Operating Cycle	: Continuous
Capacity	: Four-Person
Inlet pCO ₂ , mm Hg	: 3.0 and 2.2
Cabin Temperature, F	: 65 to 80
Cabin Pressure, psia	: 14.7
Dewpoint, F	: 40 to 60

<u>EDC Module:</u>	<u>pCO₂ = 3.0 mm Hg</u>	<u>pCO₂ = 2.2 mm Hg</u>
Air Flow Rate, acfm	: 54	58
No. of Cells	: 30	32
Active Area, ft ²	: 0.50	0.50
Current Density, ASF	: 16	16
Cell Voltage, V	: 0.45	0.45
Power, W	: (108) ^(a)	(115) ^(a)
Weight, lb	: 89	93
Volume, ft ³	: 2.36	2.49
Heat Rejection, W	: 180	192
<u>Ancillary Components:</u>		
Power, W	: 155	155
Weight, lb	: 41	41
Volume, ft ³	: 1.64	1.64
Heat Rejection, W	: 198 ^(b)	201 ^(c)
<u>Total System:</u>		
Power, W	: 90 ^(d)	86 ^(e)
Weight, lb	: 130	135
Volume, ft ³	: 4.00	4.13
Heat Rejection, W	: 378	393
O ₂ Penalty, lb/day	: 3.80	4.04
Expendable, lb/10 years	: None	None

(a) Generated power.

(b) Includes 43 W heat load for power conversion of module generated power (108 (1.0 - 0.6)) = 43 W based on 60% power conversion efficiency for EDC generated power.

(c) Assumes 46 W heat load for power conversion of module generated power (115 (1.0 - 0.06)) = 46 W.

(d) Assumes 108 W of module generated power available at a 60% power conversion efficiency (155 W - 0.6 (108) W) = 90 W.

(e) Assumes 115 W of module generated power available at a 60% power conversion efficiency (155 W - 0.6 (115)W) = 86 W.

Four-Bed Molecular Sieve Technology

The 4BMS CO₂ removal system^(14,15,16) is based on the process of chemical adsorption. Figure 42 shows the block diagram of the 4BMS CO₂ removal process for space applications. Cabin air is drawn by the fan through a desiccant bed of Molecular Sieve type 13X to dehumidify the air stream. The dehumidified air then flows through the precooler where the heat of compression, the heat generated by the blower motor and the heat of adsorption generated in the desiccant bed are removed. Next, the cooled, dry air flows through a CO₂ adsorption bed of Molecular Sieve type 5A where the CO₂ is removed and the air is heated. The warmed CO₂-free air is then passed through a desorbing desiccant bed where it is rehumidified before returning to the cabin.

As the CO₂ is adsorbed by one bed, the second bed undergoes CO₂ desorption via pressure and thermal cycling. In the desorption process, the air pump is used to save the residual air by removing it from the bed and exhausting it to the process air outlet. To facilitate CO₂ desorption, the air pump is turned off and the adsorbent bed is heated to help drive off the CO₂. As sufficiently high temperatures are reached, the CO₂ is desorbed from the zeolite surface and returns to the gas phase, causing the pressure in the bed to rise. At a given time in the half-cycle the pump is restarted, thereby removing the desorbed CO₂ and routing it to the pressurized, fixed-volume accumulator. At the end of the half-cycle, the selector valves change position, allowing the newly regenerated beds to become the adsorbing beds and vice versa, and the next half-cycle begins.⁽¹⁴⁾

One complete cycle of the 4BMS consists of each CO₂ sorbent bed undergoing an adsorption half-cycle and a desorption half-cycle. Likewise, the desiccant beds are alternatively absorbing and desorbing water. The standard half-cycle time is 90 minutes, however, the half-cycle time is adjustable.

The projected physical and operational characteristics of a 4BMS CO₂ removal system are shown in Table 15 at the two pCO₂ levels indicated.

Solid Amine CO₂ Absorption Technology

The solid amine CO₂ adsorption process uses a regenerable solid sorbent that is a weakly based ion exchange resin for CO₂ removal.^(8,17,18) The active ingredient of the resin is a polyethyleneimine ((C₂H₅N)₂)-coated microspherical acrylic substrate material (HS-C) or its derivative (HS-C+).⁽¹⁷⁾ The microspherical substrates expose large surface areas of the amine to the cabin atmosphere for CO₂ and H₂O removal. The resin chemically absorbs CO₂ by first combining with water to form a hydrated amine and then CO₂ reacts with the hydrated amine to form a bicarbonate according to the following equations, respectively:






FIGURE 42 BLOCK DIAGRAM OF 4-BED MOLECULAR SIEVE CO₂ REMOVAL SYSTEM

TABLE 15 PROJECTED PHYSICAL AND OPERATIONAL CHARACTERISTICS OF THE FOUR-BED MOLECULAR SIEVE CO₂ REMOVAL SYSTEM

Operating Cycle	: Cyclic (Variable
Capacity	: Four-Person
Inlet pCO ₂ , mm Hg	: 3.0 and 2.2
Cabin Temperature, F	: 65 to 80
Cabin Pressure, psia	: 14.7
Dewpoint, F	: 40 to 60

<u>Space Station Baseline System</u> ^(a) :	<u>pCO₂ = 3.0 mm Hg</u>	<u>pCO₂ = 2.2 mm Hg</u>
Air Flow Rate, acfm	: 12	20
Power, W	: 587	945
Weight, lb	: 408	535
Volume, ft ³	: 13.5	17.0
Heat Load, W	: 587	945
Expendables, lb/10 years		
Air	: 625	790
Water	: 89	112

Ancillary Components for CO₂ Collection^(b):

Power, W	: 250	250
Weight, lb	: 42	42
Volume, ft ³	: 3.5	3.5
Heat Load, W	: 250	250


Total System:

Power, W	: 837	1,195
Weight, lb	: 450	577
Volume, ft ³	: 17.0	20.5
Heat Load, W	: 837	1,195
Expendable, lb/10 years	: 714	902


(a) 3.0 mm Hg data Based on Ref. No. 14.

(b) Based on Ref. No. 8.

and



The amine is regenerated by applying heat to break the amine-bicarbonate bond and thus releasing the CO_2 by the following reaction:




The major components of the solid amine CO_2 removal system are the canisters containing the packed amine beds. A subsystem typically has multiple canisters depending on mission design requirements such as operational constraints, vehicle volume, crew size, power availability and maintenance/repair philosophy. A block diagram of a two-canister system is shown in Figure 43. A blower pushes cabin air through an amine canister (upper one) during the absorption cycle. Carbon dioxide and water are co-absorbed onto the sorbent media. The CO_2 and H_2O molecules are desorbed by low pressure steam. A compressor pumps the CO_2 into an accumulator for processing by a CO_2 reduction subsystem. The two-canister system operates by alternating the absorb/desorb cycles of each canister.

The projected physical and operational characteristics of a SAWD CO_2 removal system are shown in Table 16 at the two pCO_2 levels indicated.

Lithium Hydroxide CO_2 Absorption Technology

Lithium hydroxide cartridges^(18,19) have been used for CO_2 removal from air for submarines and a variety of space applications (e.g., Space Shuttle cabin air CO_2 removal, Extravehicular Mobility Unit (EMU) CO_2 removal). A block diagram of a LiOH CO_2 removal process is shown in Figure 44.

Lithium hydroxide absorbs CO_2 according to the following equation:



Because LiOH is a strong alkaline material, the efficiency of CO_2 removal is excellent; however, the reaction product, lithium carbonate (Li_2CO_3), is not readily regenerable. Therefore, continuous resupply of LiOH cartridges to, return of spent cartridges from, and storage of fresh and spent cartridges in space vehicles are required to support the long-duration space applications.

The projected physical and operational characteristics of a LiOH CO_2 removal system are shown in Table 17. No size differences were assumed for operation at 2.2 mm Hg versus 3.0 mm Hg.




FIGURE 43 BLOCK DIAGRAM OF SOLID AMINE CO₂ REMOVAL SYSTEM

TABLE 16 PROJECTED PHYSICAL AND OPERATIONAL CHARACTERISTICS OF
A STEAM DESORBED SOLID AMINE CO₂ REMOVAL SYSTEM

Operating Cycle	:	Cyclic (Variable)	
Capacity	:	Four-Person	
Inlet pCO ₂ , mm Hg	:	3.0 and 2.2	
Cabin Temperature, F	:	65 to 80	
Cabin Pressure, psia	:	14.7	
Dewpoint, F	:	40 to 60	
<u>System (Without CO₂ Collection)^(a):</u>		<u>pCO₂ = 3.0 mm Hg</u>	<u>pCO₂ = 2.2 mm Hg</u>
Air Flow Rate, scfm	:	27	35
Power, W	:	470	612
Weight, lb	:	189	220
Volume, ft ³	:	6.4	7.2
Heat Load, W	:	470	612
Expandables	:	None	None
<u>Ancillary Components for CO₂ Collection^(b):</u>			
Power, W	:	250	250
Weight, lb	:	42	42
Volume, ft ³	:	3.5	3.5
Heat Load, W	:	250	250
<u>Total System:</u>			
Power, W	:	720	862
Weight, lb	:	231	262
Volume, ft ³	:	9.9	10.7
Heat Load, W	:	720	862
Expendables, lb/10 years	:	None	None

(a) 3.0 mm Hg data based on Ref. No. 2.

(b) Based on Ref. No. 8.




FIGURE 44 BLOCK DIAGRAM OF LITHIUM HYDROXIDE CO₂ REMOVAL SYSTEM

TABLE 17 PROJECTED PHYSICAL AND OPERATIONAL CHARACTERISTICS OF
THE LITHIUM HYDROXIDE CO₂ REMOVAL SYSTEM

Operating Cycle	: Cyclic
Capacity	: Four-Person
Inlet pCO ₂ , mm Hg	: 3.0
Cabin Temperature, F	: 65 to 80
Cabin Pressure, psia	: 14.7
Dewpoint, F	: 40 to 60

Total System:

Air Flow, SCFM	: 14
Power, W	: 30
Weight, lb	: 1,613 ^(a)
Volume, ft ³	: 51.5
Heat Load, W	: 90
Expendables, lb/10 years	: 63,803

(a) For initial 90 days using data from Ref. No. 19 (1.36 lb of LiOH/lb CO₂ and 0.677 lb packaging/lb CO₂).

CO₂ Removal System Comparison Summary

Table 18 presents a side-by-side comparison of key parameters of the five CO₂ removal technologies discussed in this final report. The final basis for comparison is total equivalent weight as defined in the requirements section above. All competing systems, except for the EDC, were first sized based on inlet air pCO₂ of 3.0 mm Hg and were then adjusted for operation at an inlet air pCO₂ of 2.2 mm Hg. Test data from EDC operation at 2.2 mm Hg was also used to size an EDC at 2.2 mm Hg.

As expected the EDC results in the lowest equivalent weight by approximately a factor of two, when compared to the next best regenerative CO₂ removal technology. Also, as expected, the LiOH nonregenerative concept results in a total equivalent weight of over two orders of magnitudes larger than for example that for the EDC. The subsystem with the second lowest equivalent weight after the EDC is the APC both when compared at 3.0 mm Hg and at 2.2 mm Hg pCO₂ air inlet conditions. The APC advantage becoming greater, as expected, at the lower pCO₂ levels.

Projected APC Space Station Flight Experiment (Phase II) Configuration

Figure 45 represents the configuration of the APC subsystem that is projected to be flown as a Space Station Flight Experiment for a potential Phase II APC development effort. The subsystem consists of nine mechanical components as shown in Table 19. Readiness of each components for the flight experiment is also indicated. The APC subsystem hardware that can be flown as a Space Station experiment would look very similar to the hardware shown in Figure 46 which is a four-person capacity EDC. The EDC is similar to the ECS of an APC except that the EDC requires hydrogen at the anode side. Life Systems has over 20 years' experience in the development of EDC hardware.

The physical characteristics of such a Phase II APC are those that were presented in Table 13. Such an APC Flight Experiment could perform the actual CO₂ removal function and generate desirable low cabin pCO₂ levels aboard the Space Station, with the Baseline Space Station CO₂ Removal System, a 4BMS, functioning as the backup.

TABLE 18 EQUIVALENT WEIGHT COMPARISON OF FOUR-PERSON CAPACITY CO₂ REMOVAL SYSTEMS FOR SPACE APPLICATION AT pCO₂ LEVELS OF 2.2 AND 3.0 mm Hg

	CO ₂ Removal Technology								LiOH
	APC		EDC		4BMS		SAWD		
	2.2 mm Hg	3.0 mm Hg	2.2 mm Hg	3.0 mm Hg	2.2 mm Hg	3.0 mm Hg	2.2 mm Hg	3.0 mm Hg	
	pCO ₂	pCO ₂	pCO ₂	pCO ₂	pCO ₂	pCO ₂	pCO ₂	pCO ₂	
Power, W	763	735	86	90	1,195	837	862	720	30
Weight, lb ^(a)	252	238	135	130	577	450	262	231	1,613
Volume, ft ^{3(a)}	7.0	6.6	4.1	4.0	20.5	17.0	10.7	9.9	51.5
Heat Load, W	566	545	393	378	1,195	837	862	720	30
Expendables, lb/10 yrs	0	0	0	0	902	714	0	0	63,803
O ₂ Consumed, lb/day	0.21	0.20	4.04	3.80	0	0	0	0	0
Penalty, lb									
Power	603	581	68	71	944	661	681	569	24
Heat Load	136	131	94	91	287	201	207	173	7
Propulsion	46	44	5	5	72	50	52	43	2
O ₂ Consumed	17	16	332	312	0	0	0	0	0
Total Equivalent Wt, lb	1,054	1,010	634	609	2,782	2,076	1,202	1,016	65,449

(a) Initial launch, with 90 day resupply, as required.




FIGURE 45 APC SUBSYSTEM MECHANICAL SCHEMATIC WITH SENSORS




FIGURE 46 FOUR-PERSON CAPACITY EDC HARDWARE SIMILAR TO APC FLIGHT HARDWARE CONFIGURATION

TABLE 19 CURRENT STATUS OF APC COMPONENTS FLIGHT READINESS

<u>Components</u>	<u>Readiness^(a)</u>
1. ECS Module	4.1
2. EOS Module	4.1
3. Coolant Control Assembly	5.4
4. Filter and Isolation Valve Assemblies	5.4
5. Relative Humidity Sensors Assemblies	5.4
6. Heat Exchanger Assembly	5.4
7. Filter and Blower Assembly	5.4
8. Control/Monitor Instrumentation	8

(a) The level of components' flight readiness is based on NASA's Technology Maturity Scale as shown below:

<u>Description</u>	<u>Level</u>
Operational	8
Engineering Model Tested in Space	7.2
Engineering Model Qualified	7.1
Prototype Developed to Qualify	6.3
Prototype Tested in Test Bed - Unmanned	6.2
Prototype Tested at Contractors	6.1
Preprototype Tested at NASA	5.4
Preprototype Tested at Contractors	5.3
Major Function Tested at NASA	5.2
Major Components Tested at Contractors	5.1
Critical Hardware Tested	4.3
Critical Function Tested Over Time	4.2
Critical Function Demonstrated (Scale to Full Size)	4.1
Conceptual Design Tested Experimentally	3.2
Conceptual Design Tested Analytically	3.1
Conceptual Design Formulated	2
Basic Principles Observed and Reported	1
 (a) Definitions:	
Preprototype - Constructed of commercially available components to demonstrate fit, form and function.	
Prototype - Constructed with optimized components and packaging and subjected to design qualification environmental tests to qualify a design prior to fabrication of flight model equivalents. Prototype hardware is not intended for flight use.	
Engineering Model - Full size structural model, dimensionally correct including interfaces, and functionally identical to the flight unit but not necessarily fully qualified.	

CONCLUSIONS AND RECOMMENDATIONS

The following conclusions are derived based on the work completed:

1. An electrochemical CO₂ concentration system based on Air-Polarized Technology is the most competitive CO₂ removal system for applications where H₂ may not be desirable.
2. An APC based CO₂ removal system can effectively and efficiently remove carbon dioxide from atmosphere with CO₂ partial pressures as low as 0.3 mm Hg (equivalent to earth-like ambient conditions).
3. Operating conditions and ranges can be established that allow for integrated operation of an electrochemical CO₂ separation module and an electrochemical O₂ separation module.
4. An Electrochemical Depolarized CO₂ Concentrator (EDC) is still the most effective and efficient CO₂ removal system especially for low pCO₂ requirements and where the use of H₂ is not objectionable.
5. Scale up from previously tested single and two-cell subscale modules to five-cell electrochemical modules using flight-like sized hardware is feasible without impact on performance.
6. Based on the scaling results obtained low risk projections can be made scaling to the four-person capacity level using the operating conditions and characteristics derived as part of this effort.

The following recommendations are made based on the work performed:

1. Initiate a test program that evaluates APC technology at the approximate one person capacity level for extended period of times i.e., six month or greater.
2. Initiate a flight experiment definition study that would lead to a Preliminary Design of a one to four person capacity APC-based CO₂ removal system to flown as a Space Station Flight Experiment aboard the ISS.
3. Update the CO₂ removal system comparison study to include reliability, i.e., spares, into the total equivalent weight calculation.
4. Investigate the availability and applicability of membrane CO₂ separation (from O₂) to determine if the EOSM function can be more efficiently performed by such a membrane process.

APPENDIX A

TEST GRIDS

TABLE A-1 EOSM CHECKOUT/CALIBRATION TEST GRID

	Cathode Feed					Current, A	Coolant		Monitored Parameters, Remarks, etc.
	Rate, sccm	CO ₂ , %	P, psig	T, F	DP, F		Flow, lb/hr	Temp, F	
Assembly of Components	No	--	--	--	--	No	No	No	Verify correct installation of components
Pressure Test	No	--	--	--	--	No	No	No	Apply fluids but no flow (5 psid)
Calibration									
All sensors, gauges, flowmeters	AR ^(a)	AR	AR	AR	AR	AR	AR	AR	Some may require calibration before assembly
All actuators	No	No	No	No	No	AR	AR	AR	
Lira IR analyzer	AR	AR	AR	No	No	No	No	No	
Cathode Feed Flow	Up to 600	0	1.0	72	67	No	No	No	
Coolant Flow	No	--	--	--	--	No	50	82	
Module Operation	140 to 280	0	1.0	72	67	6.0	50	82	O ₂ Flow
Module Operation	311	55	1.0	72	67	6.0	50	82	CO ₂ /O ₂ flow

(a) AR = As Required.

10/15/96

TABLE A-2 EOSM SHAKEDOWN TEST GRID

	Cathode Feed					Current, A	Coolant		Monitored Parameters, Remarks, etc.
	Rate, sccm	CO ₂ , %	P, psig	T, F	DP, F		Flow, lb/hr	Temp, F	
Module Operation	311	55	1.0	70	57	6.0	50	70	Minimum of 24 hours continuous operation

A-3

10/15/96

TABLE A-3 EOSM DESIGN VERIFICATION TEST GRID

	Cathode Feed					Current, A	Coolant		Monitored Parameters, Remarks, etc.
	Rate, sccm	CO ₂ , %	P, psig	T, F	DP, F		Flow, lb/hr	Temp, F	
Module Operation	311	55	1.0	72	67	6.0	50	82	<ul style="list-style-type: none"> • Monitor all parameters • Adjust module coolant flow to operate cell at the specified temperature • Minimum of 3 days, with starts and stops

A-4

10/15/96

Life Systems, Inc.

TABLE A-4 EOSM PARAMETRIC TEST GRID

Rate, sccm	Cathode Feed				Current, A	Coolant		Monitored Parameters, Remarks, etc.
	CO ₂ , %	P, psig	T, F	DP, F		Flow, lb/hr	Temp, F	
140	0	1.0	72	67	6.0	50	82	Monitor all parameters
233	40	1.0	72	67	6.0	50	82	
280	50	1.0	72	67	6.0	50	82	Adjust module coolant flow to operate cell at the specified temperature and dewpoint
350	60	1.0	72	67	6.0	50	82	
175	0	1.0	72	67	7.5	50	82	
292	40	1.0	72	67	7.5	50	82	
350	50	1.0	72	67	7.5	50	82	
438	60	1.0	72	67	7.5	50	82	
117	0	1.0	72	67	5.0	50	82	
195	40	1.0	72	67	5.0	50	82	
234	50	1.0	72	67	5.0	50	82	
293	60	1.0	72	67	5.0	50	82	

A-5

10/15/96

Life Systems, Inc.

TABLE A-5 ECSM CHECKOUT/CALIBRATION TEST GRID

	Cathode Feed (Air)				Current, A	Coolant		Monitored Parameters, Remarks, etc.
	Rate, scfm	pCO ₂ , mm Hg	T, F	DP, F		Flow, lb/hr	Temp, F	
Assembly of Components	No	--	--	--	No	No	No	Verify correct installation of components
Pressure/Leak Test	No	--	--	--	No	No	No	Apply fluids but no flow (5 psid)
Calibration								
All sensors, gauges, flowmeters	AR ^(a)	AR	AR	AR	AR	AR	AR	Some may require calibration before assembly
All actuators	No	No	No	No	AR	AR	AR	
Lira IR analyzer	AR	AR	No	No	No	No	No	
Cathode Feed Flow	Up to 12.0	(b)	75	63	No	No	No	
Coolant Flow	No	--	--	--	No	50	80	
Module Operation	9.0	2.3	75	63	8.0	50	80	Anode Gas Exit Flow Rate and pCO ₂

(a) AR = As Required.

(b) Ambient.

12/20/96

TABLE A-6 ECSM SHAKEDOWN TEST GRID

	Cathode Feed (Air)				Current, A	Coolant		Monitored Parameters, Remarks, etc.
	Rate, scfm	pCO ₂ , mm Hg	T, F	DP, F		Flow, lb/hr	Temp, F	
Module Operation	9.0	2.3	75	63	8.0	50	80	Minimum of 4 hours continuous operation

A-7

12/20/96

Life Systems, Inc.

TABLE A-7 ECSM DESIGN VERIFICATION TEST GRID

	Cathode Feed (Air)				Current, A	Coolant		Monitored Parameters, Remarks, etc.
	Rate, scfm	pCO ₂ , mm Hg	T, F	DP, F		Flow, lb/hr	Temp, F	
Module Operation	9.0	2.3	75	63	8.0	50	80	<ul style="list-style-type: none"> • Monitor all parameters • Adjust module coolant and humidifier conditions to operate cell at the specified temperature and RH • Minimum of 2 days, with starts and stops

A-8

12/20/96

TABLE A-8 ECSM PARAMETRIC TEST GRID

	Cathode Feed (Air)				Current , A	Coolant		Monitored Parameters, Remarks, etc.
	Rate, scfm	pCO ₂ , mm Hg	T, F	DP, F		Flow, lb/hr	Temp, F	
Nominal Air Condition	9.0	2.3	75	63	8.0	50	80	Monitor all parameters
	9.0	2.3	75	63	4.0	50	80	
	9.0	2.3	75	63	10.0	50	80	
	9.0	3.5	75	63	8.0	50	80	
	9.0	3.5	75	63	4.0	50	80	
	9.0	3.5	75	63	10.0	50	80	
	9.0	1.0	75	63	8.0	50	80	
	9.0	1.0	75	63	4.0	50	80	
	9.0	1.0	75	63	10.0	50	80	

A-9

05/27/97

TABLE A-9 APC CHECKOUT/CALIBRATION TEST GRID

	Air Flow (ECSM)				Current, A		Module Temp., F		Coolant ECSM & EOSM		Monitored Parameters, Remarks, etc.
	Rate, scfm	pCO ₂ mm Hg	T, F	DP, F	ECSM	EOSM	ECSM	EOSM	Flow, lb/hr	Temp, F	
Assembly of Components	No	--	--	--	No	No	--	--	No	No	• Verify correct installation of components
Pressure	No	--	--	--	No	No	--	--	No	No	• Apply fluids but no flow • Bypass and Normal positions
Calibration A-10 • All sensors, gauges, flowmeters • All actuators • Lira IR analyzer	--	--	--	--	--	--	--	--	--	--	• Some may require calibration since last use
Air Flow	Up to 18.0	Amb	75	63	No	No	--	--	No	No	
Coolant Flow	--	--	--	--	No	No	--	--	50	80	
Module Delta Ps	--	--	--	--	No	No	--	--	No	No	• After charging before assembly
Module Operation ECSM	15.0	Amb	75	63	Up to 10	Up to 0.8	80	--	50	80	• CO ₂ /O ₂ and O ₂ flow
EOSM	--	--	--	--		(ECSM)	--	82	50	80	

03/20/97

TABLE A-10 APC SHAKEDOWN TEST GRID

	Air Flow (ECSM)				Current, A		Module Temp., F		Coolant ECSM & EOSM		Monitored Parameters, Remarks, etc.
	Rate,	pCO ₂	T,	DP,							
	scfm	mm Hg	F	F	ECSM	EOSM	ECSM	EOSM	Flow, lb/hr	Temp, F	
At EOSM Bypass Position:	12.0	2.3	75	63	8.0	0.0	80	82	50	80	• ECSM anode exit flow vented
• Minimum one hour continuous operation											
At Normal Position:	12.0	2.3	75	63	8.0	6.0	80	82	50	80	
• 4 hours											

A-11

03/20/97

TABLE A-11 APC DESIGN VERIFICATION TEST GRID

	Air Flow (ECSM)				Current, A		Module Temp., F		Coolant		Monitored Parameters, Remarks, etc.
	Rate,	pCO ₂	T,	DP,					ECSM & EOSM		
	<u>scfm</u>	<u>mm Hg</u>	<u>F</u>	<u>F</u>	<u>ECSM</u>	<u>EOSM</u>	<u>ECSM</u>	<u>EOSM</u>	<u>Flow, lb/hr</u>	<u>Temp, F</u>	
At Normal Position:	12.0	2.3	75	63	8.0	6.0	80	82	50	80	<ul style="list-style-type: none">• Monitor all parameters• Adjust modules' coolant flow rate and/or temperature to operate cells at the specified temperature

A-12

03/20/97

TABLE A-12 APC PARAMETRIC TEST GRID

	Air Flow (ECSM)				Current, A		Module Temp., F		Coolant ECSM & EOSM		Monitored Parameters, Remarks, etc.
	Rate, scfm	pCO ₂ mm Hg	T, F	DP, F	ECSM	EOSM	ECSM	EOSM	Flow, lb/hr	Temp, F	
pCO ₂	12.0	3.0	75	63	8.0	6.0	80	82	50	80	• Monitor all parameters
		2.3									
		1.0									
Dewpoint	12.0	2.3	75	63	8.0	6.0	80	82	50	80	• Adjust module's coolant flows rate and/or temperature to operate cells at the specified temperature and dewpoint
			80	67			83	85			
			65	40			55	60			
A-13 Current Density	12.0	2.3	75	63	8.0	6.0	80	82	50	80	
					4.0	3.0					
					10.0	7.5					

03/20/97

APPENDIX B
DATA SHEET FORMS

<i>Life Systems, Inc.</i> CLEVELAND, OHIO 44122		LOG OF TEST		SHEET 1 OF 1	DATE
		MODEL / PART NO. EOSM		TEST PLAN NO. TR-1739-3-2 PROJ. NO. 1705	
TYPE OF TEST EOSM		NAME OF RIG EOSM Test Setup		TEST ENGR. F. H. Schubert	

Data Point Number										
Date										
Time										
Amb. Temp., F										
Amb. Pres., mm Hg										
Current, A										
Cell Voltage, VDC										
Cell No. 1										
Cell No. 2										
Cell No. 3										
Cell No. 4										
Cell No. 5										
Module Voltage, VDC										
Cathode Feed										
O ₂ Flow Meter										
O ₂ Flow, accm										
CO ₂ Flow Meter										
CO ₂ Flow, accm										
O ₂ %/CO ₂ %										
Pressure, psig										
Temperature, F										
Dewpoint, F										
Coolant										
Coolant Flow Meter										
Coolant Flow, lb/hr										
Coolant Temp. Out, F										
Coolant Temp. In, F										
Product O ₂										
Volume, acc										
Time, sec										
Flowrate, accm										
Theoretical Flow, sccm										
Efficiency, %										
Cathode Exit Flow										
Volume, acc										
Time, sec										
Flowrate, accm										
Lira Reading (R_Scale)										
CO ₂ , %										

<i>Life Systems, Inc.</i> CLEVELAND, OHIO 44122		LOG OF TEST				SHEET 1 OF 2 DATE	
		MODEL / PART NO. ECSM				TEST PLAN NO. TR-1739-3-2 PROJ. NO. 1705	
TYPE OF TEST ECSM		NAME OF RIG ECSM Test Setup				TEST ENGR. F. H. Schubert	

Data Point Number											
Date											
Time											
Amb. Temp., F											
Amb. Pres., mm Hg											
Current, A (I1)											
Cell Voltage, VDC											
Cell No. 1 (E1)											
Cell No. 2 (E2)											
Cell No. 3 (E3)											
Cell No. 4 (E4)											
Cell No. 5 (E5)											
Cathode Feed (Air)											
CO ₂ Flow Meter (F3)											
CO ₂ Flow, accm											
Lira Reading (R_Scale)											
pCO ₂ , mm Hg											
pCO ₂ (Backgrd) mm Hg											
Temperature, F (T1)											
Dewpoint, F (D1)											
Coolant											
Coolant Flow Meter (F2)											
Coolant Flow, lb/hr											
Coolant Temp. Out, F (T3)											
Coolant Temp. In, F (T4)											
Product CO ₂ /O ₂											
Volume, acc											
Time, sec											
Flowrate, accm											
Flowmeter (F1)											
Dewpoint, F (D3)											
Lira Reading (R_Scale)											
CO ₂ , %											
Pressure, psig (P1)											
Cathode Exit (Air)											
Temperature, F (T2)											
Dew Point, F (D2)											
Lira Reading (R_Scale)											
CO ₂ , %											

F-606 (8/74)

B-3

 OPERATOR SIGNATURE/DATE

[illegible]

<i>Life Systems, Inc.</i> CLEVELAND, OHIO 44122		LOG OF TEST		SHEET 1 OF 3 DATE	
		MODEL / PART NO. ECSM of APC		TEST PLAN NO. TR-1739-3-2 PROJ. NO. 1705	
TYPE OF TEST INTEGRATED APC		NAME OF RIG APC Test Setup		TEST ENGR. F. H. Schubert	

Data Point Number											
Date											
Time											
Amb. Temp., F											
Amb. Pres., mm Hg											
Current, A (I1)											
Cell Voltage, VDC											
Cell No. 1 (E1)											
Cell No. 2 (E2)											
Cell No. 3 (E3)											
Cell No. 4 (E4)											
Cell No. 5 (E5)											
Cathode Feed (Air)											
CO ₂ Flow Meter (F3)											
CO ₂ Flow, accm											
Lira Reading (R_Scale)											
pCO ₂ , mm Hg											
pCO ₂ (Backgrd) mm Hg											
Temperature, F (T1)											
Dewpoint, F (D1)											
Coolant											
Coolant Flow Meter (F2)											
Coolant Flow, lb/hr											
Coolant Temp. Out, F (T3)											
Coolant Temp. In, F (T4)											
Product CO ₂ /O ₂											
Flowmeter (F1)											
Dewpoint, F (D3)											
Pressure, psig (P1)											
Cathode Exit (Air)											
Temperature, F (T2)											
Dew Point, F (D2)											
Lira Reading (R_Scale)											
CO ₂ , %											

OPERATOR SIGNATURE/DATE

REFERENCES

1. Schubert, F. H., Wynveen, R. A. and Quattrone, P. D., "Advanced Regenerative Environmental Control and Life Support Systems: Air and Water Regeneration," 25th COSPAR Meeting, Graz, Austria; July, 1984.
2. Hall, J. B. Jr., and Thomas, C. C., "Alternate Environmental Control and Life Support Systems Technologies for Space Station Application;" Paper No. 941464; 24th International Conference on Environmental Systems and 5th European Symposium on Space Environmental Control Systems; Friedrichshafen, Germany; June, 1994.
3. Lee, M. G. and Grigger, D. J., "Advanced Electrochemical Carbon Dioxide Removal Process Study," Phase I Final Report, Contract NAS9-17913, TR-1077-6A: Life Systems, Inc., Cleveland, OH; February, 1990.
4. Lee, M. G., Grigger, D. J. and Foerg, S. L., "Advanced Air Revitalization for Optimized Crew and Plant Environments," Paper No. 911501, 21st International Conference on Environmental Systems; San Francisco, CA; July, 1991.
5. Lee, M. G. and Grigger, D. J., "Advanced Electrochemical Carbon Dioxide Removal Process Study," Phase II Final Report, Contract NAS9-17913, TR-1077-7A: Life Systems, Inc., Cleveland, OH; May, 1992.
6. Lee, M. G., Grigger, D. J. and Foerg, S. L., "Electrochemical CO₂ and O₂ Separation for Crew and Plant Environments," Paper No. 921319; 22nd International Conference on Environmental Systems; Seattle, WA; July, 1992.
7. Boyda, R. B.; Lance, N. and Schwartz, M., "Electrochemical CO₂ Concentration for the Space Station Program," Paper No. 851341; 15th International Conference on Environmental Systems; San Francisco, CA; July, 1985.
8. Heppner, D. B. and Schubert, F. H., "Electrochemical and Steam-Desorbed Amine CO₂ Concentration: Subsystem Comparison," Paper No. 831120; 13th International Conference on Environmental Systems; San Francisco, CA; July, 1983.
9. Boyda, R. B.; Noble, L. D. and Bunnell, C. T., "Preprototype Electrochemical Carbon Dioxide Concentrator," Final Report, Contract NAS2-11968, TR-689-38: Life Systems, Inc., Cleveland, OH; March, 1988.
10. Kolnsberg, H. J., "Evolution of the Atmosphere Maintaining Environmental Control and Life Support Systems for United States Element of Space Station Freedom," Paper No. 941602; 24th International Conference on Environmental Systems and 5th European Symposium on Space Environmental Control Systems; Friedrichshafen, Germany; June, 1994.
11. Hall, J. B. Jr.; Pickett, S. J and Sage, K. H., "Manned Space Station Environmental Control and Life Support System Computer-Aided Technology Assessment Program," Paper No. 840957; 14th Intersociety Conference on Environmental Systems, San Diego, CA ; July, 1984.
12. Davenport, R. J.; Schubert, F. H.; Boyda, R. B. and Chang, B. J., "A Comparison of Russian and American Oxygen Generation Hardware," Paper No. 941250; 24th International

Conference on Environmental Systems and 5th European Symposium on Space Environmental Control Systems; Friedrichshafen, Germany; June, 1994.

13. Heppner, D. B.; Dahlhausen, M. J. and Schubert, F. H., "Electrochemical Carbon Dioxide Concentrator Subsystem Development," Final Report, Contract NAS2-1112, TR-482-4: Life Systems, Inc., Cleveland, OH; November, 1983.
14. Kimble, M. C.; Nacheff-Benedict, M. S.; Dall-Bauman, L. A. and Kalberg, M. R., "Molecular Sieve CO₂ Removal Systems for Future Missions Test Results and Alternative Designs," Paper No. 941396; 24th International Conference on Environmental Systems; Friedrichshafen, Germany; June, 1994.
15. Foerg, S. L.; Kallbert, M. R.; Dall-Bauman, L. A. and Sharpe, T. J., "Testing of the Integrated Air Revitalization System," Paper No. 951661; 25th International Conference on Environmental Systems; San Diego, CA; July, 1990.
16. Gentry, G. J. and Kay, R., "Space Station Freedom Carbon Dioxide Removal Flight Design," Paper No. 932108; 23rd International Conference on Environmental Systems; Colorado Springs, CO; July, 1993.
17. Kazemi, A. R. and Mitchell, S. M., "Advanced Testing and Modelling of a Modified Solid Amine Regenerative CO₂ and H₂O Removal System," Paper No. 932293; 23rd International Conference on Environmental Systems; Colorado Springs, CO; July, 1993.
18. Ouellette, F. A.; Winkler, M. E. and Smith, G. S., "The Extended Duration Orbiter Regenerable CO₂ Removal System," Paper No. 901292; 20th International Conference on Environmental Systems; Williamsburg, VA; July, 1990.
19. Personal Communications with Volosin, J., "Lunar Near-Term Configuration," Lockheed Martin; April, 1995.

